

### QUICK GUIDE: Selecting the Correct Maintenance Kit

Compressor Type



	G25 (RP25 74R) 1/4 HP	G25 (RP25 87R) 1/4 HP	G33 (RP33 71R) 1/3 HP	G33 (RP33 82R) 1/3 HP	G50 (RP50 72R) 1/2 HP	G50 (RP50 87R) 1/2 HP	G75 (RP75 72R) 3/4 HP	T75 (RP75) 3/4 HP	T100 (RP 100) 1 HP
<b>For Compressors</b>	1/4 HP Single Piston	1/4 HP Single Piston	1/3 HP Dual Piston	1/3 HP Dual Piston	1/2 HP Dual Piston	1/2 HP Dual Piston	3/4 HP Dual Piston	3/4 HP Dual Piston	1 HP Dual Piston
<b>For Compressor Models</b>	74R (2016 or Older)	87R (Post 2016)	71R (2010 or Older)	82R (Post 2010)	72R (2016 or Older)	87R (Post 2016)	72R (Post 2016)	T75 (Post 2022)	T100 (Post 2022)
<b>Used in Airmax Systems</b>	AM30, PS10	SW20HP, PS10	AM60, AM70, AM80*, AM100*	AM60, AM70, AM80*, AM100*, PS20, PS30, LS10	PS40, LS20, LS30, LS40*, LS60*	SW40HP, PS20, PS30, LS40*	PS40, PS80*, LS60*	PS40, LS80*	PS60, LS120*
<b>Maintenance Kit Required</b>	<b>SKU: 510108</b>	<b>SKU: 510510</b>	<b>SKU: 510109</b>	<b>SKU: 510111</b>	<b>SKU: 510115</b>	<b>SKU: 510511</b>	<b>SKU: 510512</b>	<b>SKU: 510541</b>	<b>SKU: 510542</b>

*\*Two Maintenance Kits will be needed, one for each compressor.*