



Laser Light Clip Mount Instructions for Use



1. Remove stake or other mounting equipment from the laser's pivot mount (see laser light unit instructions). Insert the clip mount's bolt into the hole in the laser unit's pivot mount. Depending on your laser light model, this may require screwing the bolt into the hole. Otherwise, it will simply slide in.



2. To attach the mount, screw the nut onto the bolt until tight. Make sure that the nut's grip surface is against the pivot mount. This will prevent the nut from loosening.

