

# THERMOMETER MOVEMENT INSTRUCTIONS

1. Unscrew the old cap nut (hold the indicator hand while loosening) and remove the old indicator hand.
2. Unscrew the old hex nut and remove the old thermometer movement from your thermometer base.
3. Insert the new thermometer movement into your thermometer base.
4. Tighten the new hex nut just enough that the movement will not spin easily. **DO NOT OVER TIGHTEN!**
5. Make sure the movement hanger is pointed in the correct direction for hanging your thermometer.
6. Replace the indicator hand and press on the cap nut.
7. After replacing the movement, leave the thermometer for 15 minutes in a location with a stable temperature and second reliable thermometer.
8. On the back of the thermometer is an adjustment slot. Use a coin in the adjustment slot to rotate the drum until the indicator hand displays the correct temperature. Tape can be applied across the adjustment drum and back of the movement to hold it in place.

