

4

3

2



1

B

B

A

A




DETAIL A  
SCALE 2 : 7

1. Use SILCO ET-5500 to mount to the top of the water distribution head.
2. There are **two** lock assemblies per head

### Request for Change

Name	Date
Change Requested	

	UNLESS OTHERWISE SPECIFIED:	NAME	DATE	TITLE:
	DIMENSIONS ARE IN INCHES TOLERANCES: FRACTIONAL ± ANGULAR: MACH ± BEND ± TWO PLACE DECIMAL ± THREE PLACE DECIMAL ±	DRAWN	WH	
<b>PROPRIETARY AND CONFIDENTIAL</b>  <small>THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF PSD LLC. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF PSD LLC IS PROHIBITED.</small>	INTERPRET GEOMETRIC TOLERANCING PER:	File Location:		<b>2-User Streamlav Head - Top</b>
	MATERIAL Assembly	COMMENTS:		
FINISH	DO NOT SCALE DRAWING	SCALE: 1:10	WEIGHT:	SIZE <b>B</b> DWG. NO. SL02HEADW-TOP REV 001 SHEET 1 OF 1