



## BUCKSTRUCK Card Reader Compatability List

<b>Acer</b> ICONIA A1-810, ICONIA Tab A700	<b>MOBIA</b> X8
<b>Asus</b> MeMO Pad 10 ME102, MeMO Pad ME172V, MeMO Pad ME301T, MeMO Pad ME302, Transformer Pad TF-100	<b>LG</b> G2, G3, G4, G Vista, G Pro, G Pro 2, G Pad 7.0/8.3/10.1, Optimus-G, Optimus L90
<b>Blackberry Z30</b> Z30	<b>MOBIA</b> X8
<b>Fujitsu</b> LTE F-01D	<b>Motorola</b> Droid Razr HD (XT926), Moto G, Moto X, Droid Mini, Droid Turbo*/Turbo2*, Droid Ultra * Requires Nexus Photo Viewer App (Free)
<b>Huawei</b>  MediaPad S7-301u(P), MediaPad 7 Lite, P6-00	<b>Samsung</b> Galaxy S2, S2 Plus, S3, S4, S4-Zoom, S4/S5 Active, S5, S6, S6 EDGE, S7, S7 Edge Galaxy Avant, Galaxy R, Galaxy J, Galaxy Mega 6.3, Galaxy A7, Galaxy J, WIN Galaxy Note, Note 2, 3, 4, 5, 8.0, 10.1 (2014 ed), Note Pro 12.2 Galaxy TabPro 8.4 LTE, 10.1 Galaxy Tab4 8.0, 10.1 Galaxy Tab3 - 8.0, 10.1  <i><b>NOT COMPATIBLE:</b> Galaxy S3/S4/S5 Mini's, Galaxy Core / Core Prime / Rugby Pro / Win , Galaxy Grand 2 / Grand Neo, Galaxy Tab 7.7 plus / Tab 2, Galaxy Mega 5.8 / Premier / Centura S738C, Galaxy Grand 2 / Grand Neo, Galaxy Ace / Ace 3 (GT-S7270)</i>
<b>HTC</b> Butterfly, Butterfly S, DESIRE (A8181), Desire EYE, Desire VC T328d, HTC J (Z321e), One (M8), One Max, One X	<b>Sony</b> SGPT111JP/S, SGPT112TW/S, SGPT211JP/S, Xperia AX (SO-01E), Xperia ACRO S (LT26W), Xperia T (LT30P), Xperia TX LT29i, Xperia Z2a, Xperia Z (C6602), Xperia Z ULTRA (C6802), Xperia ZL (C6502), Xperia ZR (C5502), Xperia Z3 (D6653)
<b>InFocus</b> M320	<b>Toshiba</b> AT700/35D
<b>Lenovo</b> A3000	<b>Wexler</b> Ultima 7, Ultima 7 Twist, TAB 8q, TAB 10q, Ultima Octa, Mobi 7
<b>LG</b> G2 (D800), G2 (D802), G3 (D855), G Pro (E988), G Pro 2 (D838)	<b>Xiaomi</b> MI-2s, Red Rice, Red Rice Note
	<b>ZOPO</b> ZP980