

# Putt18 Putter Selection Guide

Height - cm	Putter length - cm	RED PUTTER	RED PUTTER	GREEN PUTTER	GREEN PUTTER	BLACK PUTTER	BLACK PUTTER	BLUE PUTTER	BLUE PUTTER
91	52.07								
93.98	54.61								
96.52	54.61								
99.06	55.88								
101.6	55.88								
104.14	58.42								
106.68	59.69								
109.22	59.69								
111.76	62.23	111.76	62.23						
114.3	62.23	114.3	62.23						
116.84	64.77	116.84	64.77						
119.38	64.77	119.38	64.77						
121.92	68.58	121.92	68.58						
124.46	68.58	124.46	68.58	124.46	68.58				
127	71.12	127	71.12	127	71.12				
129.54	71.12	129.54	71.12	129.54	71.12				
132.08	71.12	132.08	71.12	132.08	71.12				
134.62	73.66			134.62	73.66	134.62	73.66		
137.16	73.66			137.16	73.66	137.16	73.66		
139.7	76.2			139.7	76.2	139.7	76.2		
142.24	78.74					142.24	78.74	142.24	78.74
144.78	78.74					144.78	78.74	144.78	78.74
147.32	78.74					147.32	78.74	147.32	78.74
149.86	78.74					149.86	78.74	149.86	78.74
152.4	81.28					152.4	81.28	152.4	81.28
154.94	83.82							154.94	83.82
157.48	83.82							157.48	83.82
160.02	86.36							160.02	86.36
162.56	86.36							162.56	86.36

*Please note: This Putter Selection Guide is to be used as a guide only.*