Brute XD Lock Instructions Supplement

The **New Brute XD** has the added extra duty lock cover. The new security cover needs to be removed in order to change the lock combination.

- Step 1. Remove the lock cover by pulling the foam back and exposing the two 7/16" hex bolts. Use a 7/16" socket to remove the bolts and cover.
- Step 2. When the security cover is removed it allows access to the the lock and "L" tab.
- Step 3. Follow the Lock Instructions supplied with your new Brute XD to change your combination.
- Step 4. Make sure your new combination is working properly and re-install the lock cover.

