



## In-Plain-Sight Shelf Adjustable Hinge Instructions

Your IPS Shelf comes with adjustable hinges. This allows you to get the perfect fit after installation. If there is a gap between the top and bottom shelf, it can be adjusted by turning the 3 screws shown below. Use a phillips head screwdriver and (A.) turn each screw counter clockwise 180° then (B.) check the gap by closing the shelf.

If visible space remains, repeat steps A. and B. again until there is no visible space between the top and bottom shelf when closed. This process can be reversed if the fit is too tight.

