

## THE PUCK" | PRODUCT GUIDE



## THE PUCK SETUP



sliding down and pulling off.



Use provided screw driver to remove battery plate screw and battery plate.



Install 4 provided AA batteries. You will want to do this even though constant power is recommended to provide a battery backup.



Re-Install battery plate and set screw.



Launch the LOCKDOWN LOGIC™ APP and follow the on screen prompts for setup.

NOTE: To provide maximum Wi-Fi range, the Puck uses 2.4GHz Wi-Fi only.

NOTE: Ensure your smart phone is connected to the same Wi-Fi network that you intend to connect your Puck.

## DOWNLOAD THE LOCKDOWN LOGIC<sup>™</sup> APP

AND CREATE AN ACCOUNT OR LOGIN TO YOUR EXISTING ACCOUNT







For Frequently Asked Questions, Videos and Setup Assistance, visit Lockdown.com/support or use the HELP section in the Logic App.

> FIND US ON SOCIAL MEDIA @LOCKDOWNSECURED

See the full line of Logic Products at LOCKDOWN.COM