

OVER THE DOOR LED BASKETBALL HOOP SET-UP INSTRUCTIONS

Our video instructions provide the best guidance for setting up your Over the Door LED Basketball Hoop. They can be viewed online at

IRUKKET.COM / **RukketSports**

Please call us if you have any questions or concerns at **1-855-4RUKKET**
Please read our product safety warnings before setup

INCLUDED EQUIPMENT



WARNING



*Please use adult supervision and follow the instructions when setting up and using this net. Regular use or abuse will eventually strain the netting and may break it. Do not pull on net or wires once the net is assembled to the hoop. Pulling on the net or wires could result in failure or damage to the product.

*Product not for outdoor use. Product is not waterproof and must be used in a cool and dry environment. Exposing the product to water before, during, or after use could result in shock or damage to the product.

*Check the wires before every use. If wires show any sign of fraying, insulation damage, or exposed wire, cease use immediately and dispose of product. Continuing to use the product with any or all of these conditions will result in damage to the product or severe injury or electrocution to the user.


PAGE 1

QUESTIONS? GIVE US A CALL! (1-855)-478-5538

IRUKKET
SPORTS

V1

OVER THE DOOR LED BASKETBALL HOOP SET-UP INSTRUCTIONS



1. Screw in both hooks on either side of the net.



2. Place 3 AA Batteries (not included) into the battery pack. Press button on battery pack to turn the lights on, then use the remote to change the lights. Turn off battery pack when not in use to preserve battery.



3. Place Velcro on the battery pack and attach it to the front of the backboard directly under the hoop. NOTE: Attaching to the front of the hoop ensures the foam sits properly against the door and should reduce the sound made by the board when shots are made at the board.



4. Place over your door and you are ready to play!