

7X7 GOLF NET


ASSEMBLY INSTRUCTIONS

HACKL100


Our video instructions provide the best guidance for setting up your 7X7 Golf Net.
They can be viewed online at




Please call us if you have any questions or concerns at **1-855-4RUKKET**
Please read our product safety warnings before setup




1. Join the two slightly bent fiberglass poles together. Then attach both end legs




2. Install the two lower fiberglass poles, with coupling tubes at the top, into the angled pipes on the metal base.




3. Thread a fiberglass pole through one of the net's sleeves making sure the net is right side up (white loops at the top corners and tag at bottom left side). Repeat for other side.



4. Insert an upper fiberglass pole into one of the lower pole's coupling tube. The metal knob should be at the top.



5. Gripping the assembled fiberglass pole, slide the net's sleeve up the pole and loop the white rope onto the metal knob on top.



6. Loop elastic bungees over clips at end of the plastic insert shape.

WARNING

Please use adult supervision and follow the instructions when setting up and using this net. Regular use or abuse will eventually strain the netting and may break it. Do not stand behind the net. This net is not intended for personal protection. This net deflects fast moving objects, so people should be at least ten (10) feet away. Prior to use inspect the netting and frame for damage or wear. Make sure the frame and net are assembled correctly and on a flat surface, at least ten (10) feet away from structures and vehicles. The user should be positioned directly in front of the net. Failure to follow these precautions could result in serious injury or damage to property.

QUESTIONS? GIVE US A CALL! (1-855)-478-5538

RUKKET
SPORTS