

RUKNET


THE ULTIMATE POP-UP NET

ASSEMBLY INSTRUCTIONS

Our video instructions provide the best guidance for setting up your Rukket.
They can be viewed online at

 /  **RukketSports**

Please call us if you have any questions or concerns at **1-855-4RUKKET**
Please read our product safety warnings before setup



- A. Carry Bag
- B. Net
- C. Stakes

QUESTIONS? GIVE US A CALL! (1-855)-478-5538



RUKKNET

THE ULTIMATE POP-UP NET

FOLDING INSTRUCTIONS


Our video instructions provide the best guidance for setting up your Rukketnet. They can be viewed online at




Please call us if you have any questions or concerns at **1-855-4RUKKET**
Please read our product safety warnings before setup




Place your Rukketnet on a flat, hard surface.



Bring the two sides together toward the center.



Lay flat on one side with the folding instructions facing up. *Be sure to align all edges.



Starting from the small end, walk across the net to the lower edge and grasp the black folding strap.



Grasping the black folding strap, lift straight up while walking backward and fold down to the attached "Fold to Here" sign.



When the edge of the net is pulled back and down to the attached "Fold to Here" sign, use one foot to hold it in place.



Keeping your foot in place, use your left hand to fold in and turn the left loop toward the center.



Keeping the left loop down, use your right hand to fold in and turn the right loop toward the center.



Once folded into three loops, be sure to align all edges while slipping the net into the carry bag.

QUESTIONS? GIVE US A CALL! (1-855)-478-5538

