RUKKNET THE ULTIMATE POP-UP NET

ASSEMBLY INSTRUCTIONS

Our video instructions provide the best guidance for setting up your Rukknet.

They can be viewed online at



Please call us if you have any questions or concerns at 1-855-4RUKKET


Please read our product safety warnings before setup

INCLUDED EQUIPMENT









- A.Target
- B. Turf
- C. Net
- D. Carry bag
- E. Stakes

RUKKNET


PERSONAL DRIVING RANGE **FOLDING INSTRUCTIONS**

Our video instructions provide the best guidance for setting up your Rukknet. They can be viewed online at







Please call us if you have any questions or concerns at 1-855-4RUKKET Please read our product safety warnings before setup




Place your Rukknet on a flat, hard surface.




Bring the two sides together toward the center.



Lay flat on one side with the folding instructions facing up. *Be sure to align all edges.



Starting from the small end, walk across the net to the lower edge and grasp the black folding strap.



Grasping the black folding strap, lift straight up while walking backward and fold down to the attached "Fold to Here" sign.



When the edge of the net is pulled back and down to the attached "Fold to Here" sign, use one foot to hold it in place.



Keeping your foot in place, use you left hand to fold in and turn the left loop toward the center.



Keeping the left lop down, use your right hand to fold in and turn the right loop toward the center.



Once folded into three loops, be sure to align all edges while slipping the net into the carry bag.

PAGE 1

RUKKNET° CHIP IT

FOLDING INSTRUCTIONS

CAUTION



Net pops open, use care.




Once Chip It has been detached hold by top corners with logo facing outwards



Once outer edges are folded inward use one hand to secure all folded edges. With the other hand fold the remaining flap up



Grasping firmly, fold outer edges inwards allowing one side to overlap the other



Once all flaps are folded use attached elastic band to secure all folds

PAGE 2