



# POP UP GOLF CHIPPING NET ASSEMBLY INSTRUCTIONS

Our video instructions provide the best guidance for setting up your Haack Golf Chipper.  
They can be viewed online at



Please call us if you have any questions or concerns at **1-855-4RUKKET**  
**Please read our product safety warnings before setup**

## INCLUDED EQUIPMENT



- A. Metal Cap
- B. Fiberglass Poles
- C. Metal Sleeve
- D. Net
- E. Metal Stakes
- F. Foam Golf Balls

QUESTIONS? GIVE US A CALL! (1-855)-478-5538




# POP UP GOLF CHIPPING NET

## ASSEMBLY INSTRUCTIONS


Our video instructions provide the best guidance for setting up your Haack Golf Chipper.  
They can be viewed online at




Please call us if you have any questions or concerns at **1-855-4RUKKET**  
**Please read our product safety warnings before setup**



1. After removing, folding, and storing the two fiberglass poles, fold the Golf Chipper flat and grasp the two upper corners.



2. Fold inward with one edge going underneath the other. The net will form itself into three circles.



3. Hold the top circles in place and fold the bottom circle onto them before placing into the carry bag.

### WARNING:

- Adult supervision is required
- Take care when opening, because the spring steel opens forcefully
  - No one should be standing near this product when it is in use
  - This product should be set up far away from people, vehicles, and structures
- Failure to follow these precautions could result in serious injury or damage to property.

QUESTIONS? GIVE US A CALL! (1-855)-478-5538

