



1. Release elastic straps on all four corners & grasp canopy at the top cap.



2. Lift the canopy off of the GenTent frame.



3. Crease canopy sides inward, allowing the front & rear panels to collapse.



4. Lay canopy on a flat surface with logo facing downward.



5. Fold canopy so that top cap is in the center of canopy. Ensure the top cap ends are flat & not flipped upward.



6. Flatten top cap and begin to roll. (Optional: Fold the electrical apron & lay it flat in the center)



7. Roll the canopy tightly from the top toward the bottom edge.



8. Rolling is complete when you see the GenTent logo face up.



9. Your GenTent canopy & frame rods can now slide easily into the storage bag. (Hardware in outer pocket).



GenTent® Accessory Bonus!

Buy any TWO (2) or more accessories receive \$10 OFF your order!

Visit GenTent.com/ReturnBonus or Call 781-334-8368.



GenTent Conversion Kit For Inverter Generators

GenTent Conversion Kit For Portable Generators



GenTent 10K Clear Vinyl OmniFit Electrical Apron



GenTent Universal Generator Folding Handles



GenSkirt 10K Full Storage Cover Conversion



GenTent Inverter Generator Spares Kit



GenTent Storage Bag



GenTent Portable Generator Spares Kit