

## Crane (Wireless remote control 1100 IB-12V)/(Wireless remote control 2200 IB-12V) manual



### Points to note:

- 1, the equipment must be fixed firmly.
2. Installation and commissioning of electrical equipment by professional personnel.

### Power installation Diagram



This product is suitable for vehicle, the required input voltage is 12V. Connect the longer end of the wire on the No. 6 fitting (power box) directly to the car power supply, and the shorter end of the wire to the winch end screw. Finally, the wired remote control can be inserted into the power box for use. We also included a wireless remote control for your use.

### List of parts

List of parts		
1	post	1PCS
2	Column of rotation	1PCS
3	Arm of connection	1PCS
4	Arm of extension	1PCS
5	winch	1PCS
6	Power supply box	1PCS
7	Wired remote control	1PCS
8	Wireless remote control	1PCS
Bag of screws	Expansion bolt *4PCS/M10 wrench *1PCS	