



**ENTOURAGE™**  
**CUP HOLDER**

User Manual

[austlen.com](http://austlen.com)

# WARNINGS & SAFETY INFORMATION

**READ THIS USER MANUAL CAREFULLY AND UNDERSTAND ALL WARNINGS AND INSTRUCTIONS BEFORE USE. YOUR CHILD'S SAFETY MAY BE AT RISK IF YOU DO NOT FOLLOW THESE INSTRUCTIONS.**

**KEEP THESE INSTRUCTIONS AND WARNINGS FOR FUTURE REFERENCE.**

DO NOT allow anyone to use this product unless that person has read and fully understood the warnings and instructions in this user manual prior to use.

## Product Care

---


Cup holder may be wiped down with water and a mild detergent, as needed. Do not use abrasives when cleaning.

# **WARNING**

- **NEVER LEAVE CHILD UNATTENDED!**
- NEVER place a hot drink in cup holder.
- NEVER allow child to play with this product.
- Maximum weight: 1 lb. (0.45 kg).
- Use of cup holder when strolling on uneven or rough terrain may result in leaks or spills.
- Use with lidless cup or container is not recommended.
- Dispose of plastic bags and packaging immediately to avoid danger of suffocation.
- Intended for use only with Austlen™ Entourage™ strollers.


## Parts List

---



## Cup Holder Installation

---




Cup holder must be aligned with right or left side protrusion located below handlebar.

**⚠ WARNING**

**NEVER** place a hot drink in cup holder.

## Cup Holder Installation

---



Cup holder snaps into place around protrusion.

Gently twist and pull cup holder to remove.

# **SUPPORT & CONTACT INFORMATION**

**Austlen™ Baby Co.  
P.O. Box 49589  
Austin, TX 78765**

**844.AUSTLEN  
support@austlen.com  
austlen.com**

**Model SA-CUPH-BK  
Manual P7400 version 1.0**

**All rights reserved. © 2016 Austlen™ Baby Co. Austlen, Entourage, and all associated logos are trademarks. All product specifications are correct at time of print. Austlen Baby Co. reserves the right to alter parts that will not affect product functionality.**