



ENTOURAGE® CAR SEAT ADAPTER
FRONT FRAME - CHICCO®

User Manual

austlen.com

WARNINGS & SAFETY INFORMATION

READ THIS USER MANUAL CAREFULLY AND UNDERSTAND ALL WARNINGS AND INSTRUCTIONS BEFORE USE. YOUR CHILD'S SAFETY MAY BE AT RISK IF YOU DO NOT FOLLOW THESE INSTRUCTIONS.

KEEP THESE INSTRUCTIONS AND WARNINGS FOR FUTURE REFERENCE.

DO NOT allow anyone to use this product unless that person has read and fully understood the warnings and instructions in this user manual prior to use.

WARNING

- **NEVER LEAVE CHILD UNATTENDED!**
- **IMPROPER ASSEMBLY, INSTALLATION OR USER CAN RESULT IN SERIOUS INJURY FROM TIPPING OR FALLING!**
- When removing infant car seat from stroller, take care that car seat does not tip and fall.
- ALWAYS use infant car seat restraint system as recommended by car seat manufacturer.
- Audible “click” on each side must be heard in order to determine that adapter is locked into stroller frame. To ensure proper locking engagement, pull outward on adapter without pressing release button. It should stay attached to frame.
- ALWAYS position car seat so that it is securely placed down onto car seat adapter. Audible “click” on each side must be heard in order to determine that car seat is locked into car seat adapter. To ensure proper locking engagement, pull up on car seat. It should remain attached to adapter.
- Weight and height limitations: DO NOT place a child in car seat that exceeds recommended height and weight specified by the car seat manufacturer.
- Only use infant car seat models approved by manufacturer with this adapter.
- Adapter not for use with child in front seat.
- Dispose of plastic bags and packaging immediately to avoid danger of suffocation.
- Follow all car seat manufacturer's instructions when using an infant car seat with the Entourage®.
- Intended for use only with Austlen™ Entourage strollers.

Compatibility

Car seat adapter is compatible with the following infant car seat models:

- Chicco® Keyfit®
- Chicco® Keyfit® 30
- Chicco® Fit 2™

Visit austlen.com for a current list of compatible infant car seats.

Care & Maintenance

PRODUCT CARE: Car seat adapter may be wiped down with water and a mild detergent that does not leave any residue, as needed.

Do not use abrasives.

Do not disassemble when cleaning.

If exposed to salt water, wipe down with fresh (tap) water as soon as possible to avoid corrosion.


Do not use pressurized water to clean.

Always dry thoroughly before storing, and do not store in a damp environment or near a direct heat source (fire, radiator, etc.)

MAINTENANCE & REPAIR: Inspect your Entourage® car seat adapter periodically. Never use a product that is structurally unsound or in need of repair. Regularly check all connecting hardware (rivets, screws, etc.) for tightness and security. Check all safety devices, locks and harnesses, for correct and secure operation.


Replace worn or broken parts as needed. Only Austlen™ Baby Co. replacement parts should be used. It may be unsafe to use parts supplied by another manufacturer.

Parts List



Installation

1 Attach / Remove Car Seat Adapter




TO ATTACH ADAPTER TO STROLLER:

STEP 1: Remove child's arm bar, and fully recline seat. Refer to Entourage® User Manual for instructions.

STEP 2: Align adapter as shown with arrow pointing up. Insert metal posts gently until adapter clicks into place.

WARNING


AVOID SERIOUS INJURY FROM TIPPING OR FALLING: ALWAYS ensure adapter is securely attached prior to use. Pull outward on adapter without pressing release button. It should stay attached to frame.



TO REMOVE ADAPTER: Push button on underside of each side to release, pull out.

Use With Infant Car Seat


1 Insert / Remove Infant Car Seat



INSERT CAR SEAT:

STEP 1: Position car seat in a rear-facing position and align support bar with the notch on the back of the car seat.


STEP 2: Slide car seat into car seat adapter until it audibly and visibly locks into place.



!WARNING

AVOID SERIOUS INJURY FROM TIPPING OR FALLING: ALWAYS ensure car seat is securely attached prior to use. Lift up on car seat to confirm it is locked into place.

DO NOT install the car seat forward-facing.



REMOVE CAR SEAT:

STEP 1: Squeeze release lever on back of car seat.

STEP 2: Pull upward on handle.

NOTE: Infant car seat must be removed before folding stroller.

Stroller will fold with front frame car seat adapter attached.

SUPPORT & CONTACT INFORMATION

Austlen™ Baby Co.
P.O. Box 49589
Austin, TX 78765

844.AUSTLEN
support@austlen.com
austlen.com

Model SA-ICFC-BK
Manual P7701 version 1.0

All rights reserved. © 2017 Austlen™ Baby Co. Austlen, Entourage®, and all associated logos are trademarks. All product specifications are correct at time of print. Austlen Baby Co. reserves the right to alter parts that will not affect product functionality.