

Grooming Arm Setup




- Step 1: Remove the Grooming Rail with Arm inside from your crate.
- Step 2: Remove velro strap holding Grooming Arm inside the rail.



Step 3: Extend the Grooming Arm at least one notch by depressing the button and sliding the bar to the next notch.





Step 4: Rotate the safety catch off the Grooming Rail's pin(1), then remove the pin (2).

Step 5: Place Grooming Arm into Grooming Rail, and reinsert the pin removed in Step 4 through the first hole in the Grooming Arm.

