

Premium Plug-In Swag Pendant







How to Assemble your Swag

- **1.** Unwrap the entire 17' cord so it hangs freely.
- **2.** Unscrew the Spider fitter cap. Attach your spider-fitter lampshade and hand tighten the cap by turning clock-wise. *Fig* (2) (If shade won't tighten properly, try turning the threaded rod with a pliers)
- **3.** Install the cylinder "Bishop" hooks on the ceiling and wall. *Fig* (3) You will want to drill 2 small pilot holes. If you are unable to screw into a stud, use the enclosed anchors.
- **4.** If you instead want to use the silver hooks, install them on the ceiling and wall, then attach the plastic holders to your cord and hang on hook. *Fig. (4)*
- **5.** Screw in a light bulb, plug in to your wall outlet, and flip the rocker switch.
- **6.** Pat yourself on the back for a great instant home makeover!

Usage Tips

- Pendants are commonly positioned at 31" above the table or counter that they are lighting. Try that height first and adjust as needed.
- For more energy-efficient lighting, try a CFL or LED bulb.
- Never exceed a 150w bulb. WARNING: Incandescent bulbs get HOT so be sure you have 2" clearance for every 50watts. (so if you use a 100w incandescent bulb, leave 4" clearance from any part of your lampshade.) CFL and LED bulbs generate much less heat per watt and are a much safer choice if you want to use a narrow lampshade.
- Too bright? You can add a dimmer switch (see LampsUSA.com and search for "dimmer") Dimmers don't work well with CFL or some LED light bulbs.
- Works great with THE MAST Swag Wall Arm for installation on your wall instead of ceiling.
- For more great lighting solutions, visit LampsUSA.com or HomeConcept.com
- Questions? Email <u>sales@HomeConcept.com</u>