


Section x-x



Trumpet Cabinet Knob W4491-38