

Inflatable Boat Cover Manual

Seamax

www.seamaxboat.com

Congratulations on your purchase of the Seamax Boat Cover, One of the best methods of protecting your inflatable boat from elements is with a well-designed and good quality cover. Covering the boat from sun damage and oxidation prevents dirt from setting on the interior and exterior and keeps moisture from causing mildew or rot to the surfaces. A nice boat cover is always a wise investment. Please take a few moments to read these instructions to become familiar with its using.



Important Safety Instructions


To guard against injury, basic safety precautions should be observed:

1. This boat cover is NOT intended to be used as a travel cover. It is intended use is to protect your boat from the elements.
2. Tie down cords or straps are not included with the package. Be sure to use, tighten and secure all straps and hooks when transporting your boat on a trailer or open vehicle. Failure to do this may cause the cover to blow off, become damaged or cause injury to others. Our product warranty does not cover any kind of loss or liability in such a situation.
3. Only use soapy water or fresh water to wash the cover. The manufacturer is not responsible for damage caused as a result of improper use or failure to observe these instructions.
4. Keep the product out of the reach of children. There may be a risk of small children choking or suffocating if they become entangled in the cover. Please SAVE this instruction manual.

Cover's Fabric

The Seamax boat cover uses Polyurethane coated PU (Polyurethane Coating); the PU layer is on one side of the fabric. This kind of fabric has high strength, durability, water resistant, UV protection, high breathability and good in almost any climate. Year-round weather conditions and usage are important to selecting the right boat cover and its fabric. The right choice can mean the difference between a boat covered in mildew and one that is just the way you left it every time and go back.

Best Fabric for Boat Cover



For Showing the Cover Only



Elastic String



Reinforced Sewing



Tie Down Rings

Specifications of Standard Fabric Grade F1 (Poor=1 ; Best=5)				
Fabric Weight	260g/SQM		UV Resistance	4
Fabric Density	600 Dtex		Breath ability	4
Water Resistance	4		Colorfastness	3
Mildew Resistance	4		Climates - Hot	4
Tensile Strength	4		Climates - Cool	5
Tear Strength	4		Warranty	2 years

Models of Boat Cover

5 SERIES & 22 MODELS: Seamax inflatable boat covers have 5 series. Each series includes a couple of sizes for different tube styles. Those sizes should be the same width. Read the “Model List” below to all our cover sizes. The bow style will not affect the cover size in most cases.

UNIVERSAL COVER: No matter which brand of boat you have, even if it is a RIB with a console, our universal cover should fit as long as your inflatable boat has a built-in transom. If you don't see a listing for your boat's measurements, please contact the seller.

MOTOR WELL DESIGN: Our boat cover should be able to cover your boat and the motor.

Models & Dimensions

A Series – for Boat’s Beam Width Range 4.3 to 4.6 feet					
Model & Max Length:	A210 – 6.9ft		A240 – 7.9ft		A265 – 8.7ft
B Series - for Boat’s Beam Width Range 4.7 to 5.2 feet					
Model & Max Length:	B255 – 8.3ft	B270 – 9.0ft	B295 – 9.7ft	B320 – 10.5ft	B350 – 11.5ft
C Series - for Boat’s Beam Width Range 5.3 to 5.7 feet					
Model & Max Length:	C300 – 9.9ft	C330 – 10.8ft	C360 – 11.8ft	C390 – 12.8ft	C420 – 13.8ft
D Series - for Boat’s Beam Width Range 5.8 to 6.4 feet					
Model & Max Length:	D370 – 12.2ft	D400 – 13.1ft	D430 – 14ft	D470 – 15.4ft	D500 – 16.5ft
E Series - for Boat’s Beam Width Range 6.6 to 7.2 feet					
Model & Max Length:	E460 – 15ft	E500 – 16.5ft	E550 – 18ft		E600 – 19.7ft

Compatible Bow Styles



- **Selecting the proper boat cover size involves just a few key pieces of information and steps. Please follow the instruction of next page to ensure you choose the right cover for your inflatable boat.**

How to Select Your Size

1. Identify your boat type, make or model. Measure the boat (length and width). To ensure you have the right measurements, be sure to measure your boat as opposed to relying on manuals or other literature.



- a. Max Length—measure from the tip of the bow to the end of the cone
- b. Beam Width—measure the widest point of the hull from pontoon edges.

2. After the boat length and beam width have been determined, you should have some additional information for picking the right cover for your inflatable boat. Cone style and having a centre console option will also have to be considered when selecting your boat cover.

IMPORTANT - BOAT STYLE INSTRUCTION

Length of Cover - Standard for 90 Degree Cone



OK for RIB, Soft Bottom Inflatables & with Motor

Boats shown below require extra length added into sizing **EXTRA**

		
45 Degree Mercury Style Need extra 6 to 10 inches	Rounded Cone Next Size Up	Central Console, Seat or Combinations Next Size Up or more

2. The most popular cone style is the 90 Degree Pointed Cone. Our boat cover design is based on this cone standard. Our boat cover will also fit many other inflatable boats. Please see our “Boat Style Instruction Photo” for finding the right size for your boat.
3. Additional of Boat Dimensions Measurement. (See Photo: Important – Boat Style Instruction)
 - Measure in a straight line (down the center of the boat), Factor in the dimensions of any additional features that will affect the cover such as a trolling motor, center console, jack plate or aftermarket pulpit or anchor davit that is not listed in this manual. Please allow a few inches of additional length to fit that equipment when picking the cover.
 - If you have a swim step, measure next from the tip of the bow to the back center of your swim platform. This is in addition to the first centerline length because some covers will fit a step and others will not so you will want to have both measurements to ensure the right selection.

Boat Cover Quick Selecting Guide

ACHILLES LT: LT2-A265 LT4-B295
ACHILLES LS-RU: LS2-A240 LS4-B270
ACHILLES LEX (WOOD FLOOR): LEX77-B255 LEX88-B270 LEX96-B295
ACHILLES LSR (ALUMINUM FLOOR): LSR290-B320 LSR310-B350
ACHILLES LSI (AIR FLOOR): LSI230-B255 LSI260-B295 LSI290-B320 LSI310-B350 LSI335-C360 LSI365-C420
ACHILLES SPD: SPD290-B320 SPD310-B350 SPD335-C390 SPD365-C420
ACHILLES RIGID HB-FX: 270FX-B295 300FX-C330
ACHILLES RIGID HB-LX: 240LX-B255 280LX-C300 315LX-C360 350LX-D400
ACHILLES RIGID HB-DX WITH SEAT & CONSOLE: HB280DX-C330 HB315DX-C390 HB350DX-D430
ACHILLES FOLDABLE: SG124-C390 SG140-D430 SG156-D500
ACHILLES FOLDABLE: SU14-D430 SU16-E500 SU18-E600

MERCURY DINGHY: 200-A210 240-A240 270-A265
MERCURY ROLL UP: 240-B270
MERCURY SPORT & ADVENTURE SPORT: 240-B270 270-B290 310-B320 340-B350
MERCURY AIR DECK (PVC/HP): 240-B270 270-B290 310-B320 340-B350
MERCURY DYNAMIC (PVC/HP): RIB260-B295 RIB280-B320 RIB310-B350
MERCURY RUNNER (PVC/HP): 300-C330 350-D400 430-D470
MERCURY HEAVY DUTY (PVC/HP): 380-D430 430-D4500
MERCURY AMANZI: 350-D430 400-E460

SEAMAX AIR: 230-A240 270-B270 320-B320
SEAMAX HD: 330-B350 360-C390 380-C420 430-D470 470-D500
SEAMAX OCEAN: 290-B295 320-B320 380-C390 430-D430
SEAMAX OCEAN-T: 380T-C390 430T-C430 470T-C470 500T-E500 530T-E550
SEAMAX SPORT/EMARINE: 240-B240 270-B270 305-B320 365-C360 420-D430
SEAMAX SR RIB: 280-C300 330-C330

ZODIAC PROJET: 350TC4-D400 420TC4-D430
ZODIAC YACHTLINE DELUXE: YL340DL-C390 YL380DL-C420 YL420DL-D500 YL470DL-E550 YL530DL-E600
ZODIAC CADET: RIB220-B255 RIB260-C300 RIB310-C360 RIB340-D400
ZODIAC COMPACT: COMPACT250-C300 COMPACT300-C330
ZODIAC CADET FASTROLLER ACTI-V: FR285-C330 FR325-C360 FR360-C390
ZODIAC CADET ROLL UP: 200-B255 240-V270 260-B295
ZODIAC CADET SOLID: 260S-C300 285S-C330 310S-C360 340S-D400
ZODIAC CADET AIRLITE: 240-B270 260-C300
ZODIAC ZOOM: 230-A265 260AERO-B295 260S-B295 310S-B350 350S-C420

Putting On


STEP 1-2: Locate the boat cover logo and start putting on the cover over the bow. Start unrolling the cover towards the back of the boat and attach the back of the cover over the ends of the pontoons. Now pull the cover over the sides of the pontoons.



STEP 3-4: Pull the Elastic String to cover the cone. If you have a motor, you can put the cover over the motor and then to the other side.



STEP 5-6: Adjust the cover by pulling the cover tight to eliminate sagging areas; Adjust the elastic string to get it snug. Always tie boat covers down securely. Avoid allowing water or snow from collecting on your cover.



Cleaning & Care

Cleaning & Storing

1. Spray down your boat cover with lukewarm water using the nozzle on your garden hose. While the cover is on top of your boat, start at the top and move left to right down the right side. Then repeat on the left. This step should help get rid of the salt or dirt if your boat is exposed to salt water.
2. Take the cover off your boat and lay it open on the ground with the side that's normally exposed to the air face up. Brush the cover with your push broom, starting at the left edge and moving to the right edge. This will remove any remaining large debris. You may need someone to stand on one edge of the cover so it doesn't roll up when you try to brush it.
3. Fill your bucket to the halfway point with water and pour in a quarter cup of a gentle soap. Do not use a detergent, since it can damage your cover's waterproofing. Stir the solution and dip your sponge in it. Use the sponge to dab any areas of your cover that are stained. Let it stand for 10 minutes.
4. Scrub your cover with your scrub brush using a circular motion until all of the stains are removed. If it takes you longer than a half hour, switch from your gentle soap to color-safe bleach, using the same measurements as before.
5. Rinse your boat cover with the hose using the method in Step 1. Let it air dry. If you have any spots on the inside of your cover, flip it over and repeat Steps 1 through 4 to get them off. Do a final rinse. Then let the cover air dry by laying it flat or hanging it over a clothesline.
6. Do NOT put your boat cover in a washing machine or dryer.
7. Store the boat cover in a bag in a clean, dry place. Ensure the cover is completely dry before storing.

Supports

We suggest you remove the cover by folding it to the centre from both sides and rolling the cover from back to front. This may make it easier to repeat the same steps when covering your boat again. (Allow the cover to dry completely before folding for storage)

Our boat covers will fit Seamax inflatable boats. And they are also suitable for all major brand names including: Achilles, Avon, Maxxon, Mercury, Zodiac, etc. We provide an extra large carrying bag for your boat cover for storage on selected models.

If you are putting your boat & cover on a road trailer, please always use heavy-duty tie down straps (Not included with cover). After driving a short distance and before go on the highway/freeway, stop and check to make sure the boat and cover are secure. Continuing to check the boat and cover frequently along the way is advised.

The boat cover support system & tie downs are inexpensive and simple accessories that lengthen the life of your cover. Extra fittings include support poles & straps. (Tie down accessories & support system is not included in the standard package).

NOTE:

Please take extra care when trying your new boat cover on for the first time. You can return the boat cover if you get the wrong size. If you must return your boat cover, it must be in the original packaging and in brand new condition. It must also be shipped prepaid.

The logo on the cover is located on the bow. We have a special design to make this cover fit your inflatable boat and motor. The cover fabric has been coated on one side with a PU layer that is water repellent.

Mildew Problems

Mildew growth on your boat can be damaging, frustrating and hazardous to your health. You can prevent mildew growth by selecting the right boat cover fabric for your climate using a vented support pole to ensure maximum breath ability and by using a boat dryer and or dehumidifier to reduce humidity under the cover. If you do end up with mildew growth on your boat cover, follow these steps to eliminate it:

1. Mix 1 cup of vinegar, 1 cup of borax powder, and 2 cups of warm water in bucket or sprayer
2. Apply the mixture to mildew spots and let set for no more than 10 minutes
3. For troublesome spots, use a soft bristle brush and scrub
4. Rinse well and allow boat cover to dry thoroughly (never use a dryer)

Warranty Policy

Finally, quality boat covers at a price that makes sense. We should have one or more boat covers that will satisfy your needs. In the meantime, we provide a 2 year limited warranty for the cover. It covers the Fabric structure, sewing lines, tie down string and elastic string.

We guarantee your purchase is brand new. Factory also inspects all shipments to try and make sure there are no missing parts and everything is in new condition. If you find any shipping damage, please contact us with a detailed picture (damaged item and package box) as soon as possible.

We will pay for the 2 way shipping within 30 days of purchase if the purchased item(s) have defects. Customer will pay for the 2 way shipping fee after 90 days when warranty service is required. If you order your boat cover in the wrong size by mistake, you can send it back within 30 days of purchase and additional shipping fee will be applied.

Seamax

www.seamaxboat.com

Distributor: Seamax Marine and Outdoor
120-11791 Machrina Way, Richmond, BC, Canada V7A 4V3
Toll free: 1-877-907-7766 Tel: 604-277-7766
Service & Warranty Return Address: Same as Above