

## IMPORTANT SAFETY INSTRUCTIONS

WHEN USING ELECTRICAL APPLIANCES, ESPECIALLY IN THE PRESENCE OF CHILDREN, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE OBSERVED, INCLUDING THE FOLLOWING: PLEASE READ THE INSTRUCTIONS CAREFULLY BEFORE USING THIS PRODUCT TO REDUCE THE RISK OF DEATH BY ELECTRIC SHOCK, FIRE, INJURY TO PERSONS AND AVOIDANCE OF BURN HAZARDS.

**-KEEP AWAY FROM WATER-**

### DANGER

WHEN THE BATTERY CHARGER IS PLUGGED INTO THE WALL SOCKET, ELECTRIC PARTS ARE STILL LIVE.

1. ALWAYS IMMEDIATELY UNPLUG THE UNIT AFTER EACH CHARGING SESSION.
2. DO NOT USE WHILE BATHING OR IN THE SHOWER.
3. DO NOT STORE OR PLACE THE APPLIANCE WHERE IT CAN FALL, OR BE PULLED INTO A SINK, TUB OR TOILETTE.
4. DO NOT PLACE IN OR DROP INTO WATER OR OTHER LIQUIDS.
5. IF THE APPLIANCE FALLS INTO THE WATER, UNPLUG IT IMMEDIATELY. DO NOT REACH INTO THE WATER.
6. UNPLUG THE APPLIANCE BEFORE CLEANING IT.

### WARNING

TO REDUCE THE RISK OF BURNS, FIRE, ELECTRIC SHOCK OR INJURY TO PERSONS:

1. THIS APPLIANCE IS FOR HOUSEHOLD USE ONLY.
2. THIS APPLIANCE SHOULD NEVER BE LEFT UNATTENDED WHEN PLUGGED IN.
3. CLOSE SUPERVISION IS NECESSARY WHEN THE APPLIANCE IS USED ON, OR NEAR CHILDREN OR INDIVIDUALS WITH CERTAIN DISABILITIES OR SPECIAL NEEDS.
4. USE THIS APPLIANCE ONLY FOR ITS INTENDED USE AS DESCRIBED IN THIS MANUAL. DO NOT USE ATTACHMENTS NOT RECOMMENDED BY THE MANUFACTURER.
5. NEVER USE THIS APPLIANCE IF IT HAS A DAMAGED CORD OR PLUG. IF IT IS NOT WORKING PROPERLY, OR IF IT HAS BEEN DROPPED, DAMAGED, OR DROPPED INTO WATER, RETURN THE APPLIANCE TO A SERVICE CENTER FOR EXAMINATION AND REPAIR.
6. KEEP THE CORD AWAY FROM HEATED SURFACES.
7. DO NOT WRAP THE CORD AROUND THE APPLIANCE.
8. NEVER USE WHILE SLEEPING.
9. NEVER DROP OR INSERT ANY OBJECTS INTO ANY OF THE APPLIANCE'S OPENINGS.
10. DO NOT USE OUTDOORS OR OPERATE WHERE AEROSOL (SPRAY) PRODUCTS ARE BEING USED OR WHERE OXYGEN IS BEING ADMINISTERED.
11. CAREFULLY EXAMINE THE INNER AND OUTER COVER OF THE APPLIANCE PRIOR TO EACH USE. DISCARD THE PRODUCT IF THE INNER OR OUTER COVER SHOWS ANY SIGNS OF DETERIORATION.
12. THIS APPLIANCE IS HOT WHEN IN USE. DO NOT LET EYES AND BARE SKIN TOUCH HEATED SURFACES.
13. DO NOT PLACE THIS APPLIANCE DIRECTLY ON ANY SURFACE WHILE IT IS HOT OR PLUGGED IN.
14. DO NOT TOUCH THE AREAS AROUND THE BATTERY DURING USE AS IT MAY BECOME HOT. IF THE UNIT OVERHEATS, UNPLUG THE BATTERY FROM THE UNIT AND LET THE UNIT AND BATTERY COOL COMPLETELY PRIOR TO RESUMING USE.
15. DO NOT USE AN EXTENSION CORD OR VOLTAGE CONVERTER WITH THIS APPLIANCE.
16. DO NOT WET OR IMMERSE THE BATTERY IN WATER OR OTHER LIQUIDS.
17. ONLY USE THE MANUFACTURER APPROVED CHARGER, USE OF A NON-APPROVED CHARGER MAY RESULT IN BATTERY FAILURE OR INJURY.
18. DO NOT SHORT CIRCUIT THE TERMINALS.
19. DO NOT DISASSEMBLE THE BATTERY.
20. DISPOSE OF USED BATTERIES ACCORDING TO LOCAL GOVERNMENT REGULATIONS.

## OPERATION WARNING

BEFORE TURNING THIS APPLIANCE ON, MAKE SURE IT IS PLACED ON A CLEAN, FLAT AND DRY SURFACE WITH NO OBSTRUCTIONS IN SIGHT.

• *DO NOT* USE THIS PRODUCT BESIDE ANY SOURCE OF WATER OR IN THE BATHROOM.



- *DO NOT* PUT BATTERY CHARGER, BATTERY OR THIS APPLIANCE, INTO WATER OR GET IT WET.
- *DO NOT* USE THIS APPLIANCE TO HEAT OTHER TYPES OF OBJECTS NOT INCLUDED IN THE APPLIANCE.
- *DO NOT* USE THIS APPLIANCE WITH OBJECTS NOT INCLUDED IN THE APPLIANCE.
- *DO NOT* PUT PARTS OR OBJECTS OTHER THAN THOSE INCLUDED IN THE PRODUCT INTO THE APPLIANCE OR ANY OF ITS OPENINGS.
- *DO NOT* SHAKE OR DROP THIS APPLIANCE.
- *ALWAYS* UNPLUG THE BATTERY CHARGER AND POWER CORD FROM THE WALL SOCKET AFTER CHARGING THE BATTERY.
- *AFTER USE*, DISCONNECT THE BATTERY FROM THIS APPLIANCE AND REMOVE THE BATTERY FROM THE BATTERY COMPARTMENT. ALLOW BOTH BATTERY AND APPLIANCE TO COOL COMPLETELY AND KEEP IN A SAFE AND DRY PLACE.
- *STORE* THE ENTIRE UNIT IN A PLACE CLEAN AND FREE OF DUST OR CHEMICAL MATERIALS.
- *DO NOT* FOLD OR CRUSH THIS APPLIANCE WHEN STORING, AS THIS MAY CAUSE SURFACE CRACKING OR PEELING.
- *DO NOT* APPLY ANY CHEMICAL MATERIALS (PIGMENT ETC.) TO SURFACES.
- *DO NOT* LET CHILDREN TOUCH OR PLAY WITH THIS APPLIANCE INCLUDING THE BATTERY CHARGER, POWER CORD AND BATTERY.



**KEEP AWAY FROM CHILDREN**

## BEAUTY TRIBE® TWO YEAR LIMITED WARRANTY TERMS AND CONDITIONS

BEAUTY TRIBE® WILL REPAIR OR REPLACE (AT OUR OPTION) BEAUTY TRIBE® PRODUCTS FREE OF CHARGE FOR TWENTY-FOUR (24) MONTHS FROM THE DATE OF PURCHASE IF THEY ARE DEFECTIVE IN WORKMANSHIP OR MATERIALS.

TO OBTAIN SERVICE UNDER THE WARRANTY PLEASE CALL 1800-838-4151 OR EMAIL US AT [INFO@BEAUTYTRIBE.COM](mailto:INFO@BEAUTYTRIBE.COM)

OR OBTAIN A RETURN AUTHORIZATION NUMBER AS WELL AS EXPLICIT INSTRUCTIONS ON HOW TO RETURN THE DEFECTIVE PRODUCT. YOU WILL BE REQUIRED TO RETURN THE DEFECTIVE PRODUCT WITH A PROOF OF PURCHASE, AND A BRIEF DESCRIPTION OF THE PRODUCTS DEFICIENCIES. PLEASE CLEARLY MARK THE RETURN AUTHORIZATION NUMBER ON THE OUTER PACKAGING WHEN SENDING US THE DEFECTIVE ITEM.

THIS WARRANTY DOES NOT COVER: (1) DAMAGE DUE TO MISUSE OR ABUSE, SUCH AS INCORRECT VOLTAGE SUPPLY, DROPPING, OR NEGLIGENCE IN SAFETY PRECAUTIONS; (2) TAMPERING, SUCH AS REPAIR OR ATTEMPTED REPAIR.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH MAY VARY FROM STATE TO STATE OR PROVINCE TO PROVINCE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OR INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES.

THIS LIMITED WARRANTY IS ONLY VALID: (1) IF PRODUCT IS REGISTERED WITH OISHI SISTERS, LLC WITHIN 21 DAYS OF PURCHASE; (2) IF THE PRODUCT IS PURCHASED WITH AN AUTHORIZED SELLER OF OISHI SISTERS, LLC. GOODS; (3) IF THE ORIGINAL SERIAL NUMBERS ON THE PRODUCT HAVE NOT BEEN REMOVED OR OTHERWISE TAMPERED WITH.

PLEASE GO TO [WWW.BEAUTYTRIBE.COM](http://WWW.BEAUTYTRIBE.COM) AND REGISTER YOUR PRODUCT UNDER THE CUSTOMER CARE CENTER AND RECEIVE PRODUCT INFORMATION UPDATES AND PROMOTIONAL OFFERS. IF YOU HAVE QUESTIONS ABOUT AFTER SALES SERVICE OR RETURNS, OUR CUSTOMER SERVICE REPRESENTATIVES WILL BE HAPPY TO HELP YOU.

VISIT: [WWW.BEAUTYTRIBE.COM](http://WWW.BEAUTYTRIBE.COM)

QUESTIONS OR COMMENTS: [INFO@BEAUTYTRIBE.COM](mailto:INFO@BEAUTYTRIBE.COM)

BEAUTY TRIBE® AND OTHER ASSOCIATED TRADEMARKS ARE OWNED BY OISHI SISTERS LLC.  
3 COLUMBUS CIRCLE  
SUITE 1500  
NEW YORK, NY 10019  
100~240VAC, 50~60HZ  
MANUFACTURED TO BEAUTY TRIBE® SPECIFICATIONS IN THE PEOPLE'S REPUBLIC OF CHINA.

# BEAUTY TRIBE®

## HYDROLIZER — CORDLESS SPA CAP CCH-1.0



## USER GUIDE

DEAR VALUED CUSTOMER,  
THANK YOU FOR PURCHASING OUR PRODUCT,  
HAPPY STYLING!

LEA, MICHIO & AKI  
THE OISHI SISTERS

## PRODUCT FEATURES

UNTIL NOW TRADITIONAL SPA CAPS HAVE BEEN DIFFICULT TO USE AND PLUG IN TYPES UNSAFE. THAT'S WHY WE CREATED THE HYDROLIZER! A REVOLUTIONARY, PATENT PENDING PRODUCT THAT SOLVES THESE PROBLEMS AND CAN HELP YOU BETTER MANAGE HAIR DAMAGED BY WINTER WEATHER, SUMMER SUN, OVER STYLING OR ENHANCE HAIR DYEING PROCESSES. OUR CORDLESS SPA CAP IS SIMPLE AND EASY TO USE FOR BOTH MEN AND WOMEN!

WITH THIS PROFESSIONAL GRADE CORDLESS SPA CAP, IN JUST 15 MINUTES OUR DEEP PENETRATING HEAT TECHNOLOGY ENHANCES CONDITIONERS, TREATMENTS AND HAIR DYES TO GET YOU ONE STEP CLOSER TO SOFTER, STRONGER MORE NOURISHED HEALTHY HAIR. WORLDWIDE VOLTAGE (120-240V) AND ITS COMPACT SIZE MEANS YOU CAN USE IT AT HOME OR WHEN YOU ARE ON THE ROAD.

THE HYDROLIZER, MAY BE USED ON ALL HAIR TYPES FOR BOTH MEN AND WOMEN! ENJOY!

PLEASE CAREFULLY READ THE INSTRUCTIONS CONTAINED IN THIS BOOKLET, AND KEEP THEM IN A SAFE PLACE FOR FUTURE USE AND STYLING REFERENCE.


- HYDROLIZER - CORDLESS SPA CAP WITH ADJUSTABLE STRING CLOSURE
- READY TO USE IN 5 MINUTES
- OVER HEAT PROTECTION MECHANISM
- 10 ONE SIZE FITS ALL ELASTICIZED DISPOSABLE CAPS
- LITHIUM ION BATTERY
- LITHIUM ION BATTERY CHARGER WITH LED INDICATOR
- APPROXIMATELY 1 HOUR OF TOTAL USAGE TIME
- CHARGING TIME APPROXIMATELY 6 HOURS
- BATTERY COMPARTMENT WITH ZIPPER
- WORLDWIDE VOLTAGE 120V-240V (PLUG ADAPTER NOT INCLUDED)
- 2 YEAR LIMITED WARRANTY
- PATENT PENDING

## MAINTENANCE AND STORAGE INSTRUCTIONS

THIS PRODUCT IS VIRTUALLY MAINTENANCE FREE. THERE ARE NO USER SERVICEABLE PARTS AND NO MAINTENANCE LUBRICATION IS NEEDED. WHEN NEEDED PLEASE :

- AFTER REMOVING THE BATTERY FROM THE BATTERY COMPARTMENT, CLEAN THE INSIDE AND OUTSIDE OF THE HYDROLIZER BY WIPING WITH A SOFT LINT-FREE WET COTTON CLOTH AND AIR DRY. DO NOT USE ANY MIST SPRAY OR CLEANSER.
- DO NOT WRAP THE POWER CORD AROUND THE BATTERY CHARGER. THIS WILL CAUSE THE CORD TO WEAR PREMATURELY AND BREAK, THUS VOIDING THE WARRANTY. AVOID JERKING, TWISTING OR STRAINING THE POWER CORD ESPECIALLY AT PLUG CONNECTIONS TO EXTEND THE LIFE OF THE CORD.
- DO NOT ATTEMPT TO REPAIR THE APPLIANCE YOURSELF.
- WHEN NOT IN USE UNPLUG THE UNIT, ALLOW IT TO COOL COMPLETELY AND STORE IT OUT REACH OF CHILDREN IN A SAFE AND MOISTURE-FREE LOCATION. DO NOT STORE IN LOCATIONS BELOW -4°F (-20°C) OR EXCEEDING 140°F (60°C).
- DO NOT FOLD OR CRUSH THIS APPLIANCE WHEN STORING, AS THIS MAY CAUSE SURFACE CRACKING OR PEELING.

HYDROLIZER  
(FRONT)



HYDROLIZER  
(BACK)



## TEN DISPOSABLE CAPS



## BATTERY PACK



## BATTERY CHARGER



## CONNECT BATTERY TO CHARGER VIA JACK



## HOW TO USE

### LITHIUM ION BATTERY CHARGER

OUT PUT 8.4V 1A

INPUT AC 110V~240V, 50/60HZ

### LITHIUM ION BATTERY

INPUT 8.4V 1A

OUTPUT 7.4V 2A (6.4V~8.4V)

1. IN AN AREA FREE AND CLEAR OF OBJECTS AND WATER SOURCES, CONNECT BATTERY CHARGER TO BATTERY VIA JACK. THEN, PLUG BATTERY CHARGER INTO THE WALL SOCKET AND CHARGE FOR 6 HOURS. THE BATTERY WILL BE FULLY CHARGED WHEN THE RED LED CHANGES TO GREEN.
2. DISCONNECT BATTERY CHARGER FROM WALL SOCKET, THEN DISCONNECT BATTERY FROM CHARGER. STORE BATTERY CHARGER IN A SAFE AND DRY LOCATION UNTIL NEXT USE.
3. OPEN THE APPLIANCE'S BATTERY COMPARTMENT AND PULL OUT BATTERY CONNECTOR. SECURELY CONNECT BATTERY TO BATTERY CONNECTOR. PLACE BATTERY INSIDE THE BATTERY COMPARTMENT AND MAKE SURE IT IS SECURELY ZIPPED CLOSED. THIS APPLIANCE SHOULD BEGIN TO WARM UP IMMEDIATELY AND WILL BE READY FOR USE IN 5 MINUTES.
4. WASH HAIR WITH SHAMPOO AS NORMAL AND GENTLY RINSE OUT EXCESS WATER.
5. STARTING AT THE CUTICLES, DISPERSE CONDITIONER THROUGHOUT ENTIRE HAIR AND SECURELY PLACE DISPOSABLE CAP OVER ENTIRE HEAD AND HAIR.
6. PLACE THIS APPLIANCE OVER ENTIRE HEAD AND SECURE INTO PLACE USING THE ADJUSTABLE STRAP.
7. LEAVE ON HAIR FOR 15 MINUTES. ONCE COMPLETED UNZIP BATTERY COMPARTMENT AND DISCONNECT BATTERY FROM THE BATTERY CONNECTOR. STORE BATTERY IN A COOL AND DRY ENVIRONMENT.
8. THOROUGHLY RINSE CONDITIONER OUT OF HAIR.
9. STYLE AS USUAL.

## USAGE TIPS

1. THIS UNIT MAY BE USED ON ALL HAIR TYPES.
2. THIS UNIT MAY BE USED ON SLIGHTLY DRY OR DAMP HAIR.
3. USE THIS APPLIANCE WITH YOUR EXISTING DAILY HAIR CONDITIONER, DEEP CONDITIONING MASK, HOMEMADE CONCOCTION OR HAIR DYE.
4. RINSING WITH COOL WATER WILL HELP CLOSE THE HAIR CUTICLE AND TIGHTEN THE HAIR SHAFT.
5. EACH INDIVIDUAL'S HAIR IS DIFFERENT; ADJUST TREATMENT TYPE AND USAGE FREQUENCY DEPENDING ON YOUR PERSONAL HAIR CARE NEEDS.
6. IF YOU HAVE A NATURALLY OILY SCALP, FOCUS ON DISPERSING THE CONDITIONER OVER THE CUTICLES WHERE IT IS MOST DAMAGED AND AVOID DISPERSING THE CONDITIONER THROUGHOUT THE ENTIRE HEAD OR DIRECTLY ONTO THE SCALP.