



Folding Bluetooth keyboard use Manual

Notice: Please read use manual carefull before you start use this product.





Support system

Win 10 /iOS/Android。

Bluetooth pairing connection



Sower switch USB charger connector

1.Please open power switch on the side of keyboard, press the short cut key FN+C to pair ,then the blue indication light flash into be searched and paired state



2. Open the tablet PC setting "Bluetooth" into searching and pairing state.



3. You will find the. "BT 3.0 Keyboard" and click to next step.



4. According the table PC tips to input the correct password then click

"Enter" button.



5. There have a tip for connecting successfully ,you can use your keyboard comfortably.

Remarks: After connecting successfully the next time you don't need match code, just open the Bluetooth keyboard power switch and the tablet PC "Bluetooth." The BT keyboard wills search the device and automatic connects.

Product features (Fn+)

IOS/Android (Press FN+ios /Android key into the corresponding system)			Windows (Press FN+Windows key into the corresponding system)		
FN+ combination key	Combination key function	Function key	FN+ combination key	Combination key function	Function key
Esc	Esc	Home	 Esc	Home	Esc
Q F1	F1	Search	Q F1	Search	F1
— F2	F2	Select	F2	Select	F2
₽ F3	F3	Сору	□ F3	Сору	F3
₽ F4	F4	Stick	₽ F4	Stick	F4
⊮ F5	F5	Cut	€ F5	Cut	F5
I -4-4 F6	F6	Progress	1 44 F6	Progress	F6
►II F7	F7	Play/Pause	►II F7	Play/Pause	F7
▶ ►1 F8	F8	Next	▶ ▶1 F8	Next	F8
◀ F9	F9	Mute	4 F9	Mute	F9
4 0 F10	F10	Volume-	4) F10	Volume-	F10
∢ 8 F11	F11	Volume+	43) F11	Volume+	F11
₽ F12	F12	Lock /Unlack Screen	₽ F12	Lock /Unlock Screen	F12
C 8	Bluetooth pairing state	+	† PgUp	PgUp	+
← Home	Home	+	∳ PgOn	PgDn	+
→ End	End	→	± End	End	→
† PgUp	PgUp	+	† PgUp	PgUp	+
↓ PgDn	PgDn	+	₽ PgOn	PgDn	+

Technical Specifications

Product Size: 275.23X88.94X6.80mm Weight: 168g Keyboard layout: 80 keys

Operating distance: 6~8m Battery capacity: 90mAh

Working voltage: 3.3~4.2V

Working current: <3mA Charging current: 150mA Standby current: < 0.4mA Sleep current: 3µA Sleep time: Ten minutes

Awaken way: Any key to awaken

Charging Method

When the voltage below 3.3V, the blue light will blink reminding tocharge. When charging the green light bright, after charging, the green light go out.

Remarks: in order to prolong the battery life, please open the keyboard power, switch when you not use.

Troubleshooting

Please contact the after-sales service.

Copyright

It is forbidden to reproduce any part of this quick start guide without the permission of seller.

Safety instructions

Do not open or repair this device, Do not use the device in a damp environment. Clean the device with a dry cloth.

Warranty

The device is provided with one-year limited hardware warranty from the purchase day.

Keyboard Maintenance

- Please keep the keyboard away from liquid or humid environment, saunas, swimming pool, steam room and don't let the keyboard get wet in the rain.
- Please don't expose the keyboard at too high or too low temperature condition.
- 3、Please don't put keyboard under sun for a long time.
- Please don't put keyboard close to the flame, such as cooking stoves, candles or fireplace.
- Avoid sharp objects scratching products, timely to recharge or replace the dry cell products to ensure the normal use.

FAQ

- 1. The tablet PC can't connect the BT keyboard?
- At first check the BT keyboard is into match code state, then open the table PC Bluetooth searching.
- Checking the BT keyboard Battery is enough, the battery low is also lead to can't connect, you need charge.
- The keyboard indication light always flashing when use?
 Keyboard indication always flashing when use, is means the battery will be no power, please charge the power as soon as quickly.
- 3. The table PC display BT keyboard is disconnect? The BT keyboard will into dormant to save the battery after some time later no use; press any key the BT keyboard will be awaken and working.

Warranty Card

User information					
Company or personage full name					
Contact address					
TELZip					
The purchased product name and model NO.					
Purchased date					

This reason due to the product broken and damage is not include on the warranty.

- Accident, misuse, improper operation, or any unauthorized repair, modified or removed
- (2) Improper operation or maintenance, when operation violation of the instructions or connection unsuitability power supply.

