

English

Puku name and logo are registered trademarks of Puku LLC.

©2013 Puku LLC. All rights reserved. Patent pending.

Designed in New York. Made in China. Puku Light Charger.



User's Manual

Puku Customer Care

Telephone: (855) 468-7858

Email: info@gotpuku.com

Hours: 8:30 AM – 7:00 PM ET Monday - Friday

Congratulations on your purchase of the Puku Light battery pack.

Section 1: Getting Started

- 1 . First, charge your Puku Light battery from a wall outlet, using the provided micro USB cable to connect your Puku Light battery to the wall charger.
- 2 . Once fully charged, the battery level indicator will turn solid white and it is ready for use.
- 3 . The Puku Light battery comes with a micro USB cable and a Lightning-to-USB cable, which can be used to charge a range of devices including smart phones, tablets and mobile or hand-held devices utilizing USB charging cables. You can also use your own USB cable that has connectors compatible with your device, including the lightning cable for the iPhone 8/7/6/5, iPad mini and other Apple devices.
- 4 . To charge your device(s), simply connect it to the OUT USB ports. Your device automatically starts charging once connected to either USB port.
- 5 . In the case your device does not automatically

- start charging, ensure it is properly connected to the battery before pushing the power button for 3-5 seconds, after which the battery should switch on and your device should start charging.
- 6 . Unplug your device once fully charged. The Puku Light shuts off automatically once your device is unplugged. The Puku Light also shuts off automatically once your device is fully charged.

Section 2: Charging Your Puku Light

Charge your Puku Light battery by simply connecting the Puku Light to the wall charger with the provided micro USB cable. After connecting to a wall outlet, you can expect the Puku Light to be fully charged within 4-5 hours. As your Puku Light charges, the battery level indicator will continue flashing a color corresponding to the battery level. The flashing indicator becomes a solid white color once the Puku Light is fully charged.

Solid White: 100%

Flashing White: 71-99%

Flashing Yellow: 41-70%

Flashing Red: 0-40%

Note: It is normal for your Puku Light to feel slightly warm while in use or being charged.

Section 3: Charging Your Device

Once a device is connected to the Puku Light, charging continues until disconnected, or until the Puku Light runs out of battery charge. If the Puku Light does not automatically detect the connected device, simply ensure your device is properly connected before pushing the power button for 3-5 seconds to switch on the battery and start charging your device.

The Puku Light can charge only one device at a time.

The Puku Light battery comes with a micro USB cable and a lightning-to-USB cable, which can be used to charge a range of devices including smart phones, tablets, mobile or hand-held devices with USB cable chargers.

The lightning-to-USB cable is compatible with the iPhone 8/7/6/5, iPads, iPods and other Apple devices. The micro USB connector is compatible

with Blackberry, HTC, LG, Nokia, Samsung, Sony and other micro USB devices including Bluetooth headsets, portable navigation devices, MP3 players, and more.

You can also use your own USB cable that has connectors compatible with your device, including connectors such as the mini USB connectors for PlayStation devices and the lightning connectors for the iPhone 5, iPad mini and other Apple devices.

Section 4: Checking Your Battery Level

The Puku Light comes with a battery level indicator that displays different colors depending on the charge level of your Puku Light.

White: 71-100%

Yellow: 35-70%

Red: 10-34%

Flashing Red: 0 <10%

You can read these battery levels either while charging your device or by simply turning on the battery. The Puku Light shuts off automatically if a

device is not being charged for more than 5 seconds.

Section 5: Maintaining your Puku Light

Please follow the maintenance instructions below in order to keep your Puku Light working optimally.

- 1 . Re-charge every three months when not in use.
- 2 . Keep dry and away from moist and corrosive materials.
- 3 . Keep clean by wiping down with cleaning cloth provided whenever necessary.

Section 6: Product Specifications

Battery: 5000 mAh Lithium Polymer

AC Input: 100-240 VAC 50/60 Hz

DC Input: 5V/2 Amp

Output: 5V/2.1Amps

Section 7: Troubleshooting

In the case your device is not charging when connected to Puku Light, ensure your device is properly connected before proceeding with pushing the power button for 3-5 seconds. Your Puku Light

should turn on and start charging your device. If the indicator on your Puku Light is flashing red, it simply means your Puku Light has run out of battery capacity and needs to be recharged.

Additionally, charging your Puku Light battery could help solve any problems associated with charging two devices at once. For more troubleshooting information, please visit www.gotpuku.com.

TWO YEAR LIMITED WARRANTY

Puku LLC sells its products with the intent that they are free of defects in manufacture and workmanship for a period of one year from the date of original purchase, except as noted below. Puku LLC warrants that its products will be free of defects in material and workmanship under normal use and service. This warranty extends only to consumers and does not extend to Retailers.

To obtain warranty service on your Puku LLC PRODUCT, contact a Customer Care Representative by telephone at 1-855-468-7858 for assistance. Please

be sure to have the model number of the product available.

Puku LLC does not authorize anyone, including, but not limited to, Retailers, the subsequent consumer purchaser of the product from a Retailer or remote purchasers, to obligate Puku LLC in any way beyond the terms set forth herein. This warranty does not cover damage caused by misuse or abuse; accident; the attachment of any unauthorized accessory; alteration to the product; improper installation; unauthorized repairs or modifications; improper use of electrical/power supply; loss of power; dropped product; malfunction or damage of an operating part from failure to provide manufacturer's recommended maintenance; transportation damage; theft; neglect; vandalism; or environmental conditions; loss of use during the period the product is at a repair facility or otherwise awaiting parts or repair; or any other conditions whatsoever that are beyond the control of Puku LLC.

This warranty is effective only if the product is purchased and operated in the country in which the product is purchased. A product that requires

modifications or adoption to enable it to operate in any other country than the country for which it was designed, manufactured, approved and/or authorized, or repair of products damaged by these modifications is not covered under this warranty.

THE WARRANTY PROVIDED HEREIN SHALL BE THE SOLE AND EXCLUSIVE WARRANTY. THERE SHALL BE NO OTHER WARRANTIES EXPRESSED OR IMPLIED INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS OR ANY OTHER OBLIGATION ON THE PART OF THE COMPANY WITH RESPECT TO PRODUCTS COVERED BY THIS WARRANTY. PUKU LLC SHALL HAVE NO LIABILITY FOR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES. IN NO EVENT SHALL THIS WARRANTY REQUIRE MORE THAN THE REPAIR OR REPLACEMENT OF ANY PART OR PARTS WHICH ARE FOUND TO BE DEFECTIVE WITHIN THE EFFECTIVE PERIOD OF THE WARRANTY.

NO REFUNDS WILL BE GIVEN. IF REPLACEMENT PARTS FOR DEFECTIVE MATERIALS ARE NOT AVAILABLE, PUKU LLC RESERVES THE RIGHT TO MAKE PRODUCT SUBSTITUTIONS IN LIEU OF REPAIR OR REPLACEMENT.

This warranty does not extend to the purchase of opened, used, repaired, repackaged and/or resealed products, including but not limited to sale of such products on Internet auction sites and/or sales of such products by surplus or bulk resellers. Any and all warranties or guarantees shall immediately cease and terminate as to any products or parts thereof, which are repaired, replaced, altered, or modified, without the prior express and written consent of Puku LLC.

This warranty provides you with specific legal rights. You may have additional rights, which may vary from state to state. Because of individual regulations, some of the above limitations and exclusions may not apply to you. For more information regarding our product line in the USA, please visit: www.gotpuku.com

Puku LLC Customer Care

Telephone: (855) 468-7858

Hours: 9:30 AM – 5:00 PM (ET) Monday - Friday

E-mail: info@gotpuku.com

WARNINGS

Read all instructions and warnings prior to using this product. Improper use of this product may result in product damage, excess heat, toxic fumes, fire or explosion, for which Puku LLC is not responsible.

1. Do not store battery in high temperature environment, including intense sunlight or heat. Do not place battery in fire or other excessively hot environments.
2. Be cautious of excessive drops, bumps, abrasions or other impacts to this battery. If there is any damage to the battery such as dents, punctures, tears, deformities or corrosion, due to any cause, discontinue use and contact the manufacturer or dispose of it in an appropriate manner.
3. Do not disassemble the battery or attempt to repair or modify it in any manner.
4. Do not expose this battery to moisture or

- submerge it in liquid. Keep battery dry at all times.
5. Do not attempt to charge battery using any other method, apparatus, or connections other than the device's micro USB connector and wall charger. For directions on the various ways to charge your Puku product please refer to the owner's manual.
 6. Do not short circuit
 7. Do not charge your device while simultaneously charging the Puku product via a wall outlet.
 8. Do not attempt to replace any part of the battery.
 9. If this battery is intended by the Purchaser to be used by a minor, purchasing adult agrees to provide detailed instructions and warnings to any minor prior to use.