




A80 SERIES

MECHANICAL KEYBOARDS

User Guide
使用说明书



New Design
New Series


Designed by IQUNIX

English Version

Start Reading →

Please read this manual guide and cautions to ensure that using this product correctly.

Details



- A Type-C Port
- B Indicator
- C Feet
- D Mode Switch
- E Silicone Pads

Product Specification

Product Name: AVER 80

Keyboard Type: Mechanical Keyboard

Key Quantity: 83 Keys

Keyboard Material: ABS Case + PBT Keycaps

Character Technology: Dye Sublimation

Large Key Structure: Costar Stabilizers

Rating: 5V=1A

Connect Interface: USB Type-C

Cable Length: 180cm

Dimensions: 321*158*52mm

Origin: Shenzhen, China



Web: www.IQUNIX.store

Support E-mail: support@iqunix.store


🔗 Three Ways of Connecting Devices






Bluetooth Connection Mode




- 1 Toggle the keyboard Mode Switch to wireless side 
 - 2 Press FN+1, then hold FN+1 for 5 seconds if the indicator blinks in blue light.
(Bluetooth matching mode on when blue light blinks.) 
 - 3 Enable Bluetooth matching (Computer / Phone / Tablet)
 - 4 Select the matching device **【IQUNIX AVER80 BT 1】**
 - 5 Indicator light turning off when matching successfully.
- !** If you need to connect a new device, please hold FN+1 for 5 seconds to remove the previous device. When the LED indicator blinks blue light, you can connect your device following the Step 3.




2.4GHz Connection Mode



- 1 Toggle the keyboard Mode Switch to “wireless mode”   
- 2 Plug the 2.4GHz receiver into your computer.
- 3 Press FN+4 to enter 2.4GHz matching mode  + 
(2.4GHz matching mode on when pink light blinks.)
- 4 Indicator light turning off means successful matching.


Wired Connection Mode



- 1 For Wireless Version, toggle the keyboard    Mode switch to wired side.
- 2 Plug the USB cable into your device.



Function Keys Combinations




LED Indicator Keys Combinations (RGB Version)



FN

Special Keys Combinations (Hold for 5 Seconds)

Mac / Windows Layout Switching



Swap CapsLock and Left Ctrl


Reset to Default

FN

Special Keys Combinations (Wireless Mode)

Switch to
Bluetooth Mode

Switch to
2.4GHz Mode







Battery Level Check

The LED Indicator blinks 1, 2, 3,...10 times,
which stands for 10%, 20%, 30%...100% battery level.

☀️ LED Indicator Status Description



Device Charging and Battery Status

 Yellow Light Blinking	 Green Light Blinking 3 Times	 Green Light On	 Red Light Blinking
Charging	Charging Completed (Wired Mode)	Charging Completed (Wireless Mode)	Less than 10% (Wireless Mode)

Bluetooth Device Matching


 Blue Light Blinking	 Turquoise Light Blinking
Bluetooth Matching on	Bluetooth Device Re-Connection

Special Status

 White Light Blinking 5 Times	 White Light On
Reset to Default	CapsLock On

2.4GHz Mode

 Pink Light Blinking
Enter 2.4GHz Mode



Mac / Windows Layout Switch



Hold for 5 seconds to switch the layout between macOS and windows systems.



To learn more details, please reach out to us on official website or social media.
Official website: www.IQUNIX.store

Follow us:
@ IQUNIX



Download IQUNIX
Official App




简体中文版

开始阅读使用



使用前请仔细阅读此说明书和注意事项
以保证您能正确的使用此产品

产品细节



- A Type-C接口
- B 指示灯
- C 脚撑
- D 切换模式开关
- E 硅胶垫

基本参数

产品名称: A80 机械键盘

键盘类型: 机械键盘

按键数量: 83

键盘材质: ABS外壳+PBT键帽

字符工艺: 热升华

大键结构: 平衡杆

额定输入: 5V=1A

接口类型: USB Type-C

数据线长: 180cm

产品尺寸: 321*159*52mm

产地: 中国深圳





官网: www.iQunix.com

邮箱: Hello@iQunix.com


选择连接方式





蓝牙模式



- 1 将键盘底部开关拨至“无线模式”  
 - 2 短按FN+1，指示灯开始闪烁青色灯光后，长按Fn+1（长按5秒钟）  + 
(指示灯开始闪烁蓝色灯光时，键盘成功进入蓝牙匹配模式。)
 - 3 打开设备（电脑、手机、平板）的蓝牙搜索界面；
 - 4 在设备的蓝牙搜索列表中选择【IQUNIX AVER80 BT 1】；
 - 5 灯光熄灭，匹配成功，开始使用您的键盘。
- ⚠ 如果需要连接新设备，需要FN+1（长按5秒钟）清除已连接的上一台设备。
待指示灯开始闪烁蓝色灯光时，即可从第三步开始进行连接。



2.4G模式




- 1 将键盘底部开关拨至“无线模式”  
- 2 将2.4G接收器接入您的电脑；
- 3 短按FN+4，进入2.4G匹配模式  + 
(指示灯开始闪烁粉色灯光时，键盘成功进入2.4G匹配模式)
- 4 灯光熄灭，匹配成功，开始使用您的键盘。

有线模式




- 1 将键盘底部开关拨至“有线模式”  
- 2 将数据线USB-A端接入电脑（有线版从此步开始）；
- 3 将数据线USB-C端接入键盘；
- 4 开始使用您的键盘。

FN 多媒体功能组合键




FN 灯光组合键 (RGB版本)



FN 特殊组合键 (长按5秒实现)

切换Mac、Windows
系统键位布局




CapsLock和
左Ctrl互换位置

恢复出厂设置

无线模式 FN 特殊组合键

切换蓝牙模式

切换2.4G模式



查看电量

指示灯闪烁1、2、3、...、10次对分别对应
电池10%、20%、30%、...、100%电量

☀ 指示灯颜色和状态说明

关于设备充电

			
黄色灯光闪烁	绿色灯光闪烁3次	绿色灯光长亮	红色灯光闪烁
充电中	充电完成(有线模式)	充电完成(无线模式)	电量低于10%(无线模式)

关于蓝牙匹配


	
蓝色灯光闪烁	设备1: 青色灯光闪烁
蓝牙匹配开启	蓝牙设备回连

关于特殊情况

	
白色灯光闪烁5次	白色灯光长亮
恢复出厂设置	Caps Lock开启

关于2.4G模式



粉色灯光闪烁
进入2.4G模式



切换为MAC布局对应的按键



长按5秒即可切换Mac、Windows系统键位布局



了解更多详细信息请关注

官方微信公众号或下载IQUNIX APP



官方微信公众号



官方APP



品牌/Brand:

IQUNIX

产地/Origin:

中国

China

制造商/Manufacturer:

深圳市银色风暴科技有限公司

Shenzhen Silver Storm Technology Co., Ltd.

服务热线/Service Telephone:

400-1788-905