



F65 SERIES







MECHANICAL KEYBOARDS

We recommend that you read this manual thoroughly before using the product.

Start Reading →

LED Indicator Status Description

The indicator is located between **G** and **H**

					
Red Light Blinking	Blue Light Blinking/Flashing	Turquoise Light Blinking/Flashing	Yellow Light Blinking/Flashing	Pink Light Blinking/Flashing	White Light On/Blinking
Low Battery Level	Bluetooth Device #1 Re-Connecting / Pairing On	Bluetooth Device #2 Re-Connecting / Pairing On	Bluetooth Device #3 Re-Connecting / Pairing On	2.4GHz Device Re-Connecting / Pairing On	CapsLock On / Special Keys Combination Enabled

🔗 Three Ways of Connecting Devices

Bluetooth Mode

① Toggle the keyboard Mode Switch to the wireless side. 

② Short Press **FN** + **Q** to make the indicator blink,


then Long Press **FN** + **Q** to make the indicator flash.

③ Select the pairing device [IQUNIX F65 BT 1]. The indicator turns off when the keyboard is paired successfully.



*In order to complete the pairing of the keyboard with a second or third new Bluetooth device, repeat the instructions from Step ② and replace the **FN** + **Q** with **FN** + **W** or **FN** + **E**.

2.4GHz Mode

- 1 Toggle the keyboard Mode Switch to the wireless side. 


- 2 Plug the 2.4GHz receiver into your computer.




- 3 Press **FN** + **R** to enter 2.4GHz connecting mode. The indicator turns off when the keyboard is connected successfully.

*Please find the 2.4GHz receiver inside the package.

Wired Mode

- 1 Toggle the keyboard Mode Switch to the wired side. 

- 2 Plug the USB cable into your device.



*When being plugged into the computer, the keyboard will start to charge automatically.


*Caution: The rated power for the charger must not exceed 5V=1A. Connection to a higher power output will damage the keyboard.



Function Keys Combinations

Hold FN first, then the corresponding keys.

- Blue Combo:** Hold FN first, then the corresponding key, and release both keys.
- Yellow Combo:** Hold FN first, then the corresponding key for 5 seconds.
- Orange Combo:** Blue Combo and Yellow Combo are both registered in the key.



Specifications

Product: F65 Mechanical Keyboard

Key Count: 67

Input: 5V=1A

Battery Specifications: 2000mAh

Precautions: See Warranty Card

Manufacturer: Shenzhen Silver Storm Technology Co., Ltd.

B306, Rongchaobinhai Bldg., 2021 Haixiu Rd., N26 Haibin Community,
Xin'an Subdistrict, Bao'an District, Shenzhen, China

Packing List: Keyboard, Dust Cover, USB Cable, 2.4GHz Receiver,
Keycap & Switch Puller, USB Extender, Manual, Warranty Card

Follow us: IQUNIX



To learn more details, please reach out to us on official website or social media.

Official website: www.IQUNIX.store