


ST-261 Unloader Valve #200261500

Part numbers on following page



ST-261 Unloader Valve #200261500

Drawing on previous page

<i>Item</i>	<i>Order #</i>	<i>Description</i>
1	040001621	Nut
2	040000390	Set screw
3	200260547	Hand wheel, complete
4	010004480	Insert adjusting screw
5	100001700	Adjusting screw
6	040001630	Set screw
7	020001341	Glide ring
8	040001610	Nut
9	060000301	Spring
10	020002850	Bushing
11	010001680	Housing
12	040001490	Cylinder pin
13	200261526	Repair kit ST-261
14	010001790	Distance piece for ST-261
15	010001690	Stop nut
*16	In Repair Kit "A"	O-ring
*17	In Repair Kit "A"	Valve part
*18	In Repair Kit "A"	Spring
*19	In Repair Kit "A"	Valve housing
20	010001700	Safety nut
21	050000440	O-ring
22	200260555	Injector nozzle 1.8 mm
23	200260556	Injector nozzle 2.1 mm
24	200260557	Injector nozzle 2.4 mm
*25	In Repair Kit "F"	Spring
*26	In Repair Kit "F"	Stainless steel ball
*27	In Repair Kit "F"	O-ring
*28	In Repair Kit "F"	Hose barb
29	050000370	O-ring
30	020001300	Injector adjustment part
31	050000530	O-ring
32	050000470	O-ring
33	010001730	Stop nut
34	020001305	Graduated collar
35	020001310	Bushing
36	050000730	Safety ring
37	040001270	Set screw
•	200261528	Repair kit "A"
*	200060720	Repair kit "F"

* Item = Individual item only available in kit listed