

COTTON SlingBelt Carrying System

Thank you for your purchase of a SlingBelt System, our best in class designs do not compromise fit, functionality or form. Our goal is single minded, to provide secure camera carrying systems that free your hands, keep your equipment safe and your body mobile, Ready To Shoot Now!



1. Secure SlingBelt around your waist using the clasp adjust to fit. to your size



4. Slide your camera in at 90 degrees




2. Secure Tether strap around the eyelet of your camera.



5. Lens down the camera locks with our patented twist & lock **Patented Twist& Lock System**



7. Add a lens bucket to one of the 2 landing pads to carry anything you need





If you have and questions or comments feel free to call or email us @

Sam@cottoncarrier.com 1-877-852-9423

www.cottoncarrier.com



3. Secure Hub with Rubber Washer to the base of your camera with the arrows facing front and back



6. Add a secondary holster to one of the 2 landing pads to carry a second camera



8. Add an Everything Bracket to secure a tripod, monopod, or whatever else you can wrap it around to make everything **Cotton Carrier compatible**