

Interlocking Tile Cleaning & Maintenance Guidelines

Annual Cleaning

Like any surface, such as concrete or asphalt a good routine maintenance program will enhance the longevity and appearance of your Rubber Walk Bonded surface/Rubber Tiles. Rubber Walk Bonded surface/Rubber Tiles will need to be vacuumed (shop vacuum) and scrubbed at spring cleaning. Remove any branches, debris or loose materials that may have accumulated over winter.

Bi-Annual Spring Cleaning

Rubber Walk bonded surface/Rubber Tiles can be additionally enhanced by cleaning with:

- a. Water hose and Spray nozzle with diluted detergent.

Procedure

1. Broom surface clear of contaminates using a stiff bristled outdoor broom
2. Dilute cleaner concentrate adding 1/4 cup per 5 gallon of hot water
3. Clean surface in 5'X5' sections applying diluted cleaner to the surface until wet
4. Thoroughly scrub surface using a stiff bristled outdoor broom.
5. Hose thoroughly. No foam or evidence of residue should be apparent after hosing

Routine cleaning (optional)

-
- 1 Depending on the frequency of use, the Rubber Walk Bonded surface/Rubber Tiles can be covered with dirt or debris that builds up with normal usage as well an accumulation of loose partial due to abrasion.

Cleaning Agents

Household cleaners (such as Dawn Dish Washing Detergent) can be used on Rubber Walk Bonded surface/Rubber Tiles. Apply to the surface using a mop or scrubbing device. This will remove most light stains.

Water Hose

Use a water hose with a spray nozzle to remove contaminants from porous surface. This is easier than using a broom. However, interior installations may place restrictions on water usage.

Advanced Maintenance

Depending on frequency of use, Rubber Walk Bonded/Rubber Tiles will occasionally need a "deep clean" to remove detrital material and/or stains.

Steam Vacuum

A Large steam vacuum with or without cleaning agents is ideal for advanced cleaning and maintenance. Follow Manufacturer's instructions.