

HEGNER MULTIMAX®-18

- | | | | | | |
|-----|----------------------|-------|---|-------|---|
| 201 | Base | 221 | Connector | 267 | Spring |
| 502 | C-Frame | 22 | Thumbscrew | 370 | Tension lever only |
| 303 | Table | 23 | Blade clamp | 371 | Tension lever rollers only |
| 304 | Upper arm | 24 | Spring | 372 | Pin |
| 305 | Lower arm | 25-46 | Screws, etc. | 373 | Tension lever roller clips |
| 306 | Table support | 350 | Blade clamp holder | 374 | Pin |
| 8 | Bushing | 251 | Thumbscrew | 465 | Switch box complete with switch and speed control |
| 9 | Bushing support | 252 | Clamp carriage | 465 H | Switch box only |
| 10 | Spring clampholder | 352 | Clamp carriage leaf spring | 200 | Holddown arm |
| 11 | Retainer | 253 | Screw | 101 | Fork |
| 212 | Tension rod | 54 | Rubber bumper | 102 | Thumbscrew |
| 214 | Table Guide | 355 | Cover | 103 | Plastic insert for holddown fork |
| 16 | Blademounting device | 56-57 | Spacer | | |
| 17 | Bellows | 58 | Spring | | |
| 218 | Air line | 59 | Washer | | |
| 19 | Motor Mx-18S | 65 | Rocker switch (wide) | | |
| 219 | Motor Mx-18V | 265 | (B) Variable speed control (board only) | | |
| 320 | Eccentric | | | | |

