

DRIVE 65MPH

AND SAVE OVER A \$1000 A YEAR IN FUEL COSTS

After talking to 1000's of Duramax owners we believe that the Duramax Diesel achieves its best mileage while driving 65MPH/1900-2000RPM. This is because this is the peak efficiency zone of the engine. **Some customers with the 6-Speed automatic transmission report better mileage running in 5th gear at less than 70 MPH.**

With the high price of diesel we all have to make the decision... do we arrive at our destination 5-10 minutes quicker... or do we save fuel costs and drive 65MPH.

HOW TO CHECK YOUR MILEAGE

The best way to determine how well the DURAMILEAGE tuning is doing for you is to measure the amount of miles you get out of a tank of fuel running stock verses DURAMILEAGE tuned. Do you drive your truck the exact same route, driving the exact same speed, with the exact same outside humidity and air temperature? Probably not. If you take in to account idling time and city driving you might not see as much calculated mpg as you will calculating how many miles driven per tank.. **We do NOT recommend using only the DIC as fuel flow changes can affect the digital read-out.**

TESTIMONIES

We always like to hear back from customers on how well the DURAMILEAGE is doing for them. **Please email us your testimony so that I can post it on our website. (we will only use your first name): testimon@dieselseries.com**

PLEASE DON'T HESITATE TO CALL IF YOU HAVE ANY FURTHER QUESTIONS AT 1-888-874-4929

THANK YOU FOR YOUR BUSINESS...

Duramileage MPG Series Module

Chevy/Gmc Duramax 6.6L


2011 – 2016 LML

Installation Instructions



Contents

1. Duramileage MPG Module
2. Wire harness cable w/ Fuel Rail Sensor connections
3. Two zip ties
4. Installation Instructions



LIMITED LIFETIME WARRANTY. Except with respect to the CALIBRATIONS, which are provided "as is" without warranty of any kind, DIESEL DOMINATION LLC warrants that the SOFTWARE PRODUCT will perform substantially in accordance with the accompanying written materials as long as it is being used by the original purchaser in the original vehicle which it was installed. To the extent allowed by applicable law, implied warranties on the SOFTWARE PRODUCT, if any, are limited to the life of the product.

Some states/jurisdictions do not allow limitations on duration of an implied warranty, so the above limitation may not apply to you.

CUSTOMER REMEDIES. DIESEL DOMINATION LLC and its suppliers' entire liability and your exclusive remedy shall be, at DIESEL DOMINATION LLC option, either:

- (a) return of the price paid, if any, or
- (b) Repair or replacement of the SOFTWARE PRODUCT provided that the SOFTWARE PRODUCT is returned to postage prepaid, with Proof of Purchase (a copy of your receipted best).

This Limited Warranty is void if failure of the SOFTWARE PRODUCT has resulted from accident, abuse, or misapplication. Any replacement SOFTWARE PRODUCT will be warranted for the remainder of the original warranty period.

Outside the United States, these remedies are not available without Proof of Purchase from an authorized international source.

NO OTHER WARRANTIES. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, DIESEL DOMINATION LLC AND ITS SUPPLIERS DISCLAIM ALL OTHER WARRANTIES AND CONDITIONS, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE AND NON-INFRINGEMENT, WITH REGARD TO THE SOFTWARE PRODUCT, AND THE PROVISION OF OR FAILURE TO PROVIDE SUPPORT SERVICES. THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY HAVE OTHERS, WHICH VARY FROM STATE/JURISDICTION TO STATE/JURISDICTION.

LIMITATION OF LIABILITY. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL DIESEL DOMINATION LLC OR ITS SUPPLIERS BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION, OR ANY OTHER PECUNIARY LOSS) ARISING OUT OF THE USE OF OR INABILITY TO USE THE SOFTWARE PRODUCT OR THE FAILURE TO PROVIDE SUPPORT SERVICES, EVEN IF DIESEL DOMINATION LLC HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN ANY CASE, DIESEL DOMINATION LLC'S ENTIRE LIABILITY UNDER ANY PROVISION OF THIS EULA SHALL BE LIMITED TO THE AMOUNT ACTUALLY PAID BY YOU FOR THE SOFTWARE PRODUCT AND/OR EQUIPMENT. BECAUSE SOME STATES/JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

AGREEMENT. By installation you agree that you have read this entire document and accept the above terms & conditions and you are accepting full responsibility that Diesel Domination LLC products and software will be handled as described above.

YOUR WARRANTY IS YOUR RESPONSIBILITY

PLEASE FAMILIARIZE YOURSELF WITH YOUR VEHICLES "OWNER MANUAL" CONCERNING AFTERMARKET PRODUCT INSTALLATION... IF IN DOUBT CALL YOUR DEALER!

BY INSTALLATION OF ANY AFTERMARKET PRODUCT YOU ACCEPT COMPLETE PERSONAL RESPONSIBILITY FOR YOUR WARRANTY CLAIMS... DO NOT PURCHASE PRODUCTS FROM DIESEL DOMINATION LLC UNLESS YOU ARE WILLING TO ACCEPT THIS RESPONSIBILITY!

Contact Information
Diesel Domination LLC
3100 Arabian Road
Helena, MT 59602
Ph: 888-874-4929
Tech: 888-842-7557

120 Day SATISFACTION GUARANTEE

Diesel Domination offers its customers a 120 day satisfaction guarantee. Our 120 Day satisfaction guarantee begins from the date the Module was shipped to you.

Returning the Duramileage Series Module for Warranty Exchange

You may have warranty issues handled two ways.

1. Return the product to the dealer/distributor that you purchased the MPG Module from. However, you must call them first and explain the problem and get a return authorization number from them.
2. You can return the MPG Module to Diesel Domination LLC. (Whether you purchased directly from Diesel or not). However, you must call Diesel Domination first and explain the problem you are having and only then you will get a warranty authorization number from them. No packages will be accepted that do not have a warranty authorization number.

Return Policy

1. All Returns Must Have RMA#. Packages sent to Diesel Domination without a RMA# will be refused and sent back to sender.
2. To Receive a RMA# please call our Tech. Support at 888-842-7557. Inform them of any issue you may have and they will issue a RMA#.
3. Module must be returned in undamaged condition. We will not refund purchase price if module has been damaged by user.
4. Module must be received back to Diesel Domination within 120 day guarantee period to receive refund of purchase price less any shipping charges.

Product Disclaimer / END-USER LICENSE AGREEMENT

Copyright laws and international copyright treaties, as well as other intellectual property laws and treaties protect the SOFTWARE PRODUCT. The SOFTWARE PRODUCT is licensed, not sold. NOTE: The terms of a printed, paper EULA, which may accompany the SOFTWARE PRODUCT, supersedes the terms of any on-screen EULA found within the SOFTWARE PRODUCT.

CALIBRATION RIGHTS AND LIMITATIONS

Custom Calibrations are the intellectual property of Diesel Domination LLC. Calibration files are provided by as part of the purchase price of the medium to which they are programmed into. You may not reverse engineer, descramble or by any other means determine the tuning methods Diesel Domination LLC employs to create its performance calibrations.

Custom Calibrations are not EPA or CARB certified and are sold strictly for off-road use except where expressly stated. Diesel Domination LLC provides custom calibrations strictly "AS IS" and is not responsible for any special, incidental, indirect or consequential damages whatsoever (including, without limitation, damages for loss of vehicle use, business interruption, or any other pecuniary loss) arising out of the use of or inability to use the custom calibrations, even if Diesel Domination LLC. has been advised

1. Locate Fuel Rail Sensor on driver side of motor.



2. Disconnect Fuel Sensor connectors.



3. Plug male end of the module's Fuel Sensor plug into the truck's female connector. Next, plug female end of the module's Fuel Sensor plug into the truck's male connector.
4. Use zip ties provided to mount module away from extremely hot and/or moving parts.
5. Start the vehicle and insure plugs were fully connected. You will hear or feel a Click when connector latches properly.

Please Note

If you get a (CEL) Check Engine Light upon installation:

****Check to insure the wire-harness connectors and sensor connectors are completely connected as an incomplete connection will cause a CEL.**

**** Most auto parts stores will allow you to use their code scanners to check what the CEL code is for free.**

If you need to take your vehicle in for service work, remove the module before service work is performed.

**Any Questions please
call our Tech Support:
888-842-7557**