
$V \cdot V \cdot 0$



Black 2-in-1 Footrest & Ottoman for Desk

SKU: CHAIR-FR01 Instruction Manual



A CAUTION! A

If you do not understand these directions, or if you have any doubts about the safety of the installation, please contact our product support team at 309-278-5303 or help@vivo-us.com for further assistance. Check carefully to make sure there are no missing or defective parts. Improper installation may cause damage or serious injury. Do not use this product for any purpose that is not explicitly specified in this manual. Do not exceed weight capacity. We cannot be liable for damage or injury caused by improper mounting, incorrect assembly or inappropriate use.



WARNING: CHOKING HAZARD

SMALL PARTS - NOT FOR CHILDREN UNDER 3 YEARS. ADULT SUPERVISION IS REQUIRED.



DO NOT EXCEED WEIGHT CAPACITY

FAILURE TO DO SO MAY RESULT IN SERIOUS INJURY.

We're Here for You

Open Monday - Friday 7:00am - 7:00pm CST,

our dedicated support team can offer immediate assistance with rapid response times. If any parts are received damaged or defective, please contact us. We are happy to replace parts to ensure you have a fully functioning product.



Give us a Call:

309-278-5303

AVG. RESOLUTION TIME (within office hrs): 5M 4S



Chat Us:

www.vivo-us.com

AVG. RESOLUTION TIME (within office hrs): < 15 M



Email Us:

help@vivo-us.com

AVG. RESPONSE TIME (within office hrs): 1HR 8M

- 23% within < 15m
- 38% within < 30m
- 61% within < 1hr
- 83% within < 2hr
- 92% within < 3hr

Package Contents



A (x1) Base




B (x1) Mesh Pad

Weight Capacity:




STEP 1

Unfold Base (A).




STEP 2

Press Mesh Pad (B) into the top of Base (A) making sure the keyed sections are aligned. You will hear a click once the pieces are secured.



STEP 3

Once Mesh Pad (B) is secured to Base (A), you can adjust the height by holding down Base (A) and pulling up on Mesh Pad (B). To lower the height, pull Mesh Pad (B) to the top of the height range to reset the racthening system then lower to the bottom range to re engage the ratchet. Mesh Pad (B) can be removed by pulling on the lever on the underside of Mesh Pad (B) and pulling away from Base (A).



3



Need Help? Get In Touch

Monday-Friday from 7:00am-7:00pm CST



help@vivo-us.com



www.vivo-us.com
Chat live with an agent!



309-278-5303



