


Pneumatic Arm Single Monitor Wall Mount Instruction Manual



SKU: MOUNT-V001A



Scan the QR code with your mobile device or follow the link for helpful videos and specifications related to this product.

https://vivo-us.com/products/mount-v001a

GET IN TOUCH | Monday-Friday from 7:00am-7:00pm CST








WARNING!

If you do not understand these directions, or if you have any doubts about the safety of the installation, please call a qualified technician. Check carefully to make sure there are no missing or defective parts. Improper installation may cause damage or serious injury. Do not use this product for any purpose that is not explicitly specified in this manual. Do not exceed weight capacity. We cannot be liable for damage or injury caused by improper mounting, incorrect assembly or inappropriate use.



NOTE: NOT ALL HARDWARE INCLUDED WILL BE USED



A CAUTION!

DO NOT INSTALL INTO DRYWALL ALONE. VERIFY YOUR WALL CONSTRUCTION. USE WOOD STUDS TO MOUNT. We include mounting for brick and concrete walls. If unsure, please contact us at vivo-us. com, email at help@vivo-us.com, or call us at 309-278-5303.

TOOLS NEEDED **Phillips** Screwdriver Pencil





WARNING: CHOKING HAZARD


SMALL PARTS - NOT FOR CHILDREN UNDER 3 YEARS. ADULT SUPERVISION IS REQUIRED.

ASSEMBLY STEPS

STEP 1


OPTION A: Wood Wall

Use a pencil to mark drilling location for wood beam and drill 2.2" deep holes using 3/16" bit. Use of a studfinder is recommended. Mount Arm (A) to wall using Wall Screws (W-A) and Washers (W-C). Do NOT use Anchors (W-B) for wood beam installation.




OPTION B: Concrete/Brick

Use a pencil to mark drilling location for wood beam and drill 2.4" deep holes using 3/8" bit. Use of a studfinder is recommended. Mount Arm (A) to wall using Wall Screws (W-A), Washers (W-C), and Anchors (W-B) for concrete or brick wall installation.




3

STEP 2




STEP 3




STEP 4

Tighten the socket screw if the joints are making a popping sound. Adjust arm tension by turning the screw with 5mm Allen Wrench (**T-A**). Clockwise reduces tension, counterclockwise increases tension. The tension should be just enough to hold your monitor in place without lifting itself up. If needed, adjust bolts on the sides of the hinge behind the VESA plate to tighten or loosen the tilt angle.



STEP 5



STEP 6 Insert cables and replace cover while making sure the cables have enough slack to allow enough free movement of the arm.





Open Monday - Friday 7:00am - 7:00pm CST,

our dedicated support team can offer immediate assistance with rapid response times. If any parts are received damaged or defective, please contact us. We are happy to replace parts to ensure you have a fully functioning product.

 \subseteq

help@vivo-us.com

AVG. RESPONSE TIME (within office hrs): 1HR 8M

- 23% within < 15m
- 38% within < 30m
- 61% within < 1hr
- 83% within < 2hr
- 92% within < 3hr



www.vivo-us.com
Chat live with an agent!

AVG. RESOLUTION TIME (within office hrs): < 15 M



309-278-5303

AVG. RESOLUTION TIME (within office hrs): 5M 4S