

TV Wall Mount and Entertainment Shelf

Instruction Manual



SKU: MOUNT-VW11



Scan the QR code with your mobile device or follow the link for helpful videos and specifications related to this product.

https://vivo-us.com/products/mount-vw11

GET IN TOUCH | Monday-Friday from 7:00am-7:00pm CST



help@vivo-us.com




www.vivo-us.com Chat live with an agent!



309-278-5303

WARNING!

If you do not understand these directions, or if you have any doubts about the safety of the installation, please call a qualified technician. Check carefully to make sure there are no missing or defective parts. Improper installation may cause damage or serious injury. Do not use this product for any purpose that is not explicitly specified in this manual. Do not exceed weight capacity. We cannot be liable for damage or injury caused by improper mounting, incorrect assembly or inappropriate use.



NOTE: NOT ALL HARDWARE INCLUDED WILL BE USED



A CAUTION!

DO NOT INSTALL INTO DRYWALL ALONE. VERIFY YOUR WALL CONSTRUCTION. USE WOOD STUDS TO MOUNT. We include mounting for brick and concrete walls. If unsure, please contact us at vivo-us. com, email at help@vivo-us.com, or call us at 309-278-5303.

TOOLS NEEDED





DO NOT EXCEED WEIGHT CAPACITY.

Failure to do so may result in serious injury.





WARNING: CHOKING HAZARD


SMALL PARTS - NOT FOR CHILDREN UNDER 3 YEARS. ADULT SUPERVISION IS REQUIRED.

ASSEMBLY STEPS

STEP 1


OPTION A: Wood Wall

Use TV plate **(A)** to mark mounting locations on wall for drilling. Use of a stud finder is highly recommended. Drill 1.2" deep holes with a 3mm or 1/8" drill bit, and anchor TV mounting plate **(A)** to wall using screws **(M)** and washers **(L)**.



OPTION B: Concrete Ceiling


Use TV plate (A) to mark mounting locations on wall for drilling. Drill 2.4" deep holes using 10mm or 13/32" drill bit. Press anchors (N) into wall, and anchor TV mounting plate (A) to wall using screws (M) and washers (L).




STEP 2


Assemble mounting bracket (**D**) to hangers (**C**) at desired height using nuts (**Q**) and washers (**O**). Screw plastic thumb screws (**P**) through front of hangers (**C**) and thumb screws (**T**) through back of shelf mounting bracket.

STEP 3







STEP 5



Assemble TV brackets **(B)** to TV using appropriate mounting screws **(G, H, I, J)** and washers **(K)**. Ensure that VESA brackets are positioned with slots on top and holes on bottom, and with the tilt adjustment knobs facing away from each other.







Open Monday - Friday 7:00am - 7:00pm CST,

our dedicated support team can offer immediate assistance with rapid response times. If any parts are received damaged or defective, please contact us. We are happy to replace parts to ensure you have a fully functioning product.

 \subseteq

help@vivo-us.com

AVG. RESPONSE TIME (within office hrs): 1HR 8M

- 23% within < 15m
- 38% within < 30m
- 61% within < 1hr
- 83% within < 2hr
- 92% within < 3hr



www.vivo-us.com
Chat live with an agent!

AVG. RESOLUTION TIME (within office hrs): < 15 M



309-278-5303

AVG. RESOLUTION TIME (within office hrs): 5M 4S