

SB Metropolis Instructions

Your SB Metropolis timepiece...

- is manufactured with either a Ronda 715 Swiss quartz movement for **3-Hand watches**; a Ronda 5030D Swiss quartz movement for **Chronograph watches**; or a Seiko NH35 Automatic Movement for **Lumatic watches**.
- has a scratch-resistant Sapphire crystal installed.
- is water-resistant to 5 ATM or 165 feet.
- is 100% pure, nickel-free stainless steel.
- has a date feature located at 6 o'clock.



Date Setting for all models

Pull the crown to pos.1. Turn knob clockwise to desired date. Push the crown to its original position.

Time Setting for all models

Pull the crown to pos. 2, adjust the time. Push the crown to its original position.

Chronograph Instructions

A. To operate chronograph,
Button A: Start/Stop;
Button B: Reset

B. Chronograph hands zero reset:

1. Pull crown to 2nd click position.
2. Push buttons **A & B** simultaneously for 2 seconds+ then press **A** to advance hand to zero position. Press **B** to go to the next counter hand.
3. To adjust "hour" counter hand, click **A** (1x short or continuous).
4. To adjust "minute" counter hand press **B**, then press **A** (1x short or continuous).
5. To adjust "second" counter hand, press **B**, then press **A** (1x short or continuous).
6. Return crown to closed position.

