



## QS10 - CHIMNEY STARTER

### *To Use:*

1. Remove labels from product.
2. Place crumpled newspaper in bottom of chimney.
3. Place chimney on center of charcoal grate.
4. Fill chimney with charcoal.
5. Light crumpled newspaper through holes in bottom of chimney.
6. Allow coals to heat for 10-15 minutes.
7. Use caution when pouring hot coals into grill.
8. Allow chimney to cool before placing in a safe non-combustible area away from children.

