

# MILLION TREE WATCH

Warranty & Manual



TruWood

*"Look deep into nature and you will  
understand everything better"*

*- Albert Einstein*

## **Table of Contents**

1. Adjusting the Strap
2. General Care
3. Displays & Buttons
- 4.1 Setting the Time
- 4.2 Setting the Date
- 5.1 Removing the Wood Link Band
- 5.2 Attaching the Leather Strap
6. 1-Year Limited Manufacturer Warranty

# Adjusting the Strap

## Adjusting the Strap: Use a Professional

All our wooden straps are made with removable links that make the strap fully adjustable to fit any wrist size. We highly recommend taking the watch to a professional jeweler in order to adjust the strap to minimize potential damage to the watch. Incorrect removal of the band will violate the 1-year manufacturer warranty.

## Adjusting the Strap: At Home

If you decide to adjust your strap at home using a *TruWood Watch Link Removal Tool* (or other), then please make sure you remove the pins in the direction of the diagram below and re-insert them in the *opposite* direction:



# General Care

## **Water: Avoid When Possible**


Although our watches are splash proof (small contact with water) it is best practice to avoid water when possible. Over time, water can penetrate the wood and leave stains.

Swimming, showering or submerging your watch under water is not recommended.

## **Polishing & Cleaning**

To polish your new watch, apply 2 sprays of water or olive oil to the cleaning cloth provided and gently rub the cloth over the wooden parts of the watch 3-4 times.

# Displays & Buttons



# Setting The Time

The normal position for the crown is pushed in all the way.

- 1) Remove the plastic knob stopper between the crown and the case.
- 2) Pull the crown until it pops out to the 2nd click position.
- 3) Turn the crown to set the hour and the minute hands.
- 4) Once the time has been set, push the crown back into the normal position. The second hand will begin to run.

# Setting The Date

- 1) Pull the crown out to the 1st click position.
- 2) Turn the crown counter-clockwise to set the date.  
**NOTE:** If the date is set between the hours of around 9:00 PM and 1:00 AM, the date may not change the following day.
- 3) After the date has been set, push the crown back to the normal position.

# Swapping the Watch Strap

Your Million Tree watch comes with a replacement leather strap. Here's how to swap it in from the default wood link band.

## Removing the Wood Link Band

1) Lay watch face down on a towel. Using the pick tool that came with your watch, insert the end into the small gap right under the case back, where the spring bar is visible to catch the shoulder (ridge) of the spring bar.



2) Depress the spring bar by applying pressure with the tool towards the watch band. When the spring bar is clear of the lug, that side of the band will drop down and out of the watch case.




3) Rotate watch around and repeat these steps to the other side of the watch band. The watch is now ready for the leather replacement strap.



# Attaching the Leather Strap

1) Keep your watch laying face down. Install the buckle side strap on the top of the watch (at 12 o'clock). Insert one end of the spring bar into the hole on the watch lug.



2) Depress the other end of the spring bar by applying pressure towards the strap with the pick tool or your fingers on the protruding spring shoulder on the underside of the strap. Slide spring bar inside the hole of the watch lug. Make sure both ends of the spring bar securely snap into their holes.



3) Repeat these steps to install the point side of the strap, which goes on the bottom of the watch (at 6 o'clock). Now you're all done!



**NOTE:** Do NOT use this tool for adjusting the wood link band length (like on page 1). This does not act as a watch link removal tool.



# 1-Year Limited Manufacturer Warranty

TruWood offers a one year warranty from the date of purchase on all internal parts of the watch which are related to the time-keeping mechanism.

The warranty does not cover accidental damage to the band, case or glass of the watch. Damage that occurs due to incorrect removal of the links from the band is also not covered by the warranty.

If you have any special circumstances, please shoot us an email at [info@mytruwood.com](mailto:info@mytruwood.com) and we will do our best to accommodate you. We're human too!