

getting started with Acrylographs



Activating/Reactivating

shake cap firmly on, shake vigorously
↓
press nib firmly on paper until ink flows
↓
repeat if needed
↓
CREATE and have FUN!!

Storage

wipe nib down and
store horizontally

Nib Sizes

0.7mm 
3mm 

Cleaning

hold the pen upright, gently remove nib
soak in warm soapy water
scrub with sponge or toothbrush if needed

Tips to prevent clogging

- do not leave the pens open for a long period of time
- ensure the lid is on correctly
- layer colours when the ink is dry
- wipe off any excess ink