LAPCO FR™
Coveralls Size Chart

- To find your coverall size, measure your chest, waist, and inseam. Choose the corresponding size.
- If you are between sizes, choose the larger size.
- When taking your measurements, use a cloth tape measure, not a metal one.
- Measurements should be taken over standard undergarments.
- If you plan to wear clothing beneath your coveralls, order one size larger, to accomodate the extra garments.

CVFRD7 · CVEFR7 · NXCCE45 · CVIN9 · CVDHF6

ALPHA COVERALL SIZING (inches)

ALPHA SIZES	SM	MED	LAR	XL	2XL	3XL	4XL	5XL	6XL
CHEST/WAIST	34-36	38-40	42-44	46-48	50-52	54-56	58-60	62-64	66-68
NOTE:	*If waist size is larger than chest size, use your waist measurement to find your size.*								

GOCD6 · GOCD7

NUMERIC COVERALL SIZING (inches)

NUMERIC SIZE / CHEST/WAIST	34	36	38	40	42	44	46	48	50	52	54	56	58	60	62	64	66	68
ALPHA EQUIVALENT	SM		MED		LG		XL		2XL		3XL		4XL		5XL		6XL	
NOTE:	*If waist size is larger than chest size, use your waist measurement to find your size.*																	

INSEAM LENGTHS

LENGTH	INSEAM
SHO	28" inseam with short length torso
REG	30" inseam with standard length torso
TAL	32" inseam with tall length torso
XTA	34" inseam with extra tall length torso

Differences between LAPCO FR Regular Sizing & Short, Tall, and Extra Tall:

-Short sizes are 1/2" shorter than Regular sizes in the Torso.
-Short sleeve lengths are 1" shorter than Regular sleeve lengths.

-Tall sizes are 1/2" longer than Regular sizes in the Torso.
-Tall sleeve lengths are 1" longer than Regular sleeve lengths.

-Extra Tall sizes are 1" longer than Regular sizes in the Torso.
-Extra Tall sleeve lengths are 1.5" longer than Regular sleeve lengths.

**Stock sizes shown. Special order sizes may be available by request.

How to Choose Your Coverall Size

If your chest measurement is larger than your waist measurement use your chest measurement to find your size.

However, if your waist measurement is larger than your chest measurement use your waist measurement to find your size.