

LAPCO FR™

Winter Wear Size Chart

Insulated Coats, Jackets, Bibs & Coveralls

- To find your jacket size, measure your chest.
- For insulated coverall sizing, use chest and inseam measurements.
- **If your waist size is larger than your chest size, use your waist measurement to choose your size.**
- To find your insulated bib overall size, use your waist and inseam measurements.

COATS, JACKETS, INSULATED BIBS & COVERALLS SIZING

ALPHA SIZES	SM	MED	LAR	XL	2XL	3XL	4XL	5XL	6XL
CHEST/WAIST MEASUREMENT	30-32"	34-36"	38-40"	42-44"	46-48"	50-52"	54-56"	58-60"	62-64"

FR INSULATED COVERALL & OVERALL LENGTHS*

LENGTHS	HEIGHT
REG	5'8" - 6'0"
TAL	6'1" - 6'5"

NOTE:

When taking your measurements, use a cloth tape measure, not a metal one. Measurements should be taken over standard undergarments.

PRO TIP: *If you plan to wear clothing beneath your bibs or coveralls, choose a larger size, to accomodate the extra garments.*