

LAPCO FR™

Hoodies Size Chart

SWHFR14 & SWHFR14Z

- To find your size, use your chest measurement.
- **Double the chest width below and match to your chest measurement.**
- If you are in between sizes, choose the larger size.

SHIRT MEASUREMENTS			
ALPHA SIZE	CHEST WIDTH	BACK LENGTH	SLEEVE LENGTH
SM	24 7/8	26 3/8	26 1/4
MED	25 5/8	27	26 3/4
LAR	26 3/8	27 1/2	27 1/4
XL	27 1/8	28 1/8	27 3/4
2XL	27 7/8	28 5/8	28 1/4
3XL	28 5/8	29 1/4	28 3/4
4XL	29 3/8	29 3/4	29 1/4
5XL	30 1/8	30 3/8	29 3/4
6XL	30 7/8	30 7/8	30 1/4

NOTE:

When taking your measurements, use a cloth tape measure, not a metal one. Measurements should be taken over standard undergarments.

