

Indoor Programmable Light Control Instructions

CL11 / 3075405

This Light Control can be programmed to automatically turn your light fixture "ON" at dusk and "OFF" after 2, 5, or 8 hours depending how you program it.

1. Plug lamp into light control and control into a nearby AC outlet leaving lamp switch and any wall switch in an "ON" position. Light control should be connected to a wall outlet so the photoelectric eye is exposed to natural light. Avoid placing near artificial or reflected indoor light. The Light Control is reset to programmed time, when the photoelectric eye turns off the light. **DO NOT PLACE BEHIND FURNITURE OR COVER UNIT WITH DRAPERY.** Each room has different light conditions - experiment to find the best wall outlet for using your light control.
2. Unit is programmed by simply pressing the Timer button. The first push of this button will cause the light to flash 1 time and set the control to turn the light off after 2 hours. The second push of this button will cause the light to flash 2 times and set the control to turn the light off after 5 hours. The third push of this button will cause the light to flash 3 times and set the control to turn the light off after 8 hours. The fourth push of this button will cause the light to flash 4 times and set the control to turn the light off at dawn. To confuse possible intruders, a press of the Random button will choose at random between 2, 5, or 8 hours off after light turns on at dusk. Each night the control will choose a different time until control is re-programmed or the power is turned off. A press of the Auto button turns your light fixture on at dusk and off at dawn.
3. Your Light Control is now programmed.
4. In the case of power failures, the control will still operate each day, once power is restored, defaulting to dusk to dawn until you re-program it. To re-program, simply follow these instructions again, starting with #2.

⚠ Caution: Do not exceed lamp wattage specified on lamp fixture.

Note: For indoor use. For use with incandescent and compact fluorescent bulbs 200 Watts or less. Do not use this control with another light control or dimmer in the same circuit.

1 Year Warranty

AmerTac™ warrants this product to be free from defects in material and workmanship for a period of 1 year from the date of purchase. AmerTac's obligations are limited to repairing or replacing any defective units and are effective only if such units are returned within 1 year of the purchase date, to AmerTac™, 250 Boulder Drive, Breinigsville, PA 18031. Warranty void if damage is due to accident, negligence, misuse, alteration or improper installation. In no circumstance will AmerTac be liable for consequential or incidental damages relating in any way to this product.

Questions, ¿Preguntas?, La question? 1-800-777-0802

©2008 AmerTac™

250 Boulder Drive

Breinigsville, PA 18031

www.amertac.com

Made in China / Hecho en China / Fabriqué en Chine

I05-0009-A

