




www.pixiogaming.com




## **Operations Guide**





**Part Name** 




## **Operation Parts for Attention**

WARNING

\* Ignoring content might cause casualties resulting in mistakes in operation \*

DON'T put by articles of high temperature Overheating of green screen may cause fire

DON'T let children play with the screen Problems may occur if not handled with proper care





The green screen is heavy, be careful of fingers and toes when handling product May cause injuries and/or damage the product if not paid close attention


DON'T store the screen in an angle The screen has a danger of falling down if leaned against a wall Please level the screen on ground level




DON'T touch the surface of the screen with hands DON'T draw or write directly on the screen DON'T touch the screen with any sharp or hard surfaces

For safety and cleanliness, please restore the screen inside the shell after use In order to clean the screen, gently brush off any dirt or dust with a clean cotton cloth







2. Open the lid by releasing the clip.



3. Open the lid.



4. To extend the screen from the container, slowly pull out the screen at a perpendicular angle using the handle.



5. Pull up the screen until it reaches the desired length.

*Ρixio*