











Freedom E-Desk™

FDM-E-DESK





Caution: Do not exceed maximum listed weight capacity. Serious injury or property damage may occur.



Important Information:

1. Heavy product, after opening the box, lift the product from the box with an additional person is recommended.
2. After plugging in the power, the power indicator lights up. Press "up button", the worktop raises; press "down button", the worktop goes down.
3. Make sure all cord lengths are sufficient to use with this product.