
|·\/

35.25" x 23.25" Electric Desk Riser

Instruction Manual



SKU: DESK-V000EB



Scan the QR code with your mobile device or follow the link for helpful videos and specifications related to this product.

https://vivo-us.com/products/desk-v000eb



help@vivo-us.com





www.vivo-us.com

1-800-371-5654


WARNING!

If you do not understand these directions, or if you have any doubts about the safety of the installation, please call a qualified technician. Check carefully to make sure there are no missing or defective parts. Improper installation may cause damage or serious injury. Do not use this product for any purpose that is not explicitly specified in this manual and do not exceed weight capacity. We cannot be liable for damage or injury caused by improper mounting, incorrect assembly, or inappropriate use.


$\underline{\wedge}$ ELECTRICAL SAFETY INSTRUCTIONS

THIS PRODUCT IS POWERED BY ELECTRICITY. IN ORDER TO AVOID BURNS, FIRE AND ELECTRIC SHOCK, PLEASE READ THE FOLLOWING INSTRUCTIONS CAREFULLY.

- DO NOT CLEAN PRODUCT WHILE POWER IS CONNECTED.
- DO NOT DISASSEMBLE OR REPLACE COMPONENTS WHILE POWER IS CONNECTED.
- NEVER OPERATE THE SYSTEM WITH A DAMAGED CORD OR PLUG. PLEASE CONTACT YOUR SELLER TO REPLACE DAMAGED PARTS.
- NEVER OPERATE SYSTEM IN DAMP ENVIRONMENTS OR IF ANY ELECTRICAL COMPONENTS HAVE
 MADE CONTACT WITH LIQUIDS.
- ALTERATIONS OF THE GIVEN POWER UNIT ARE NOT ALLOWED.
- OUTDOOR USE IS PROHIBITED.








Phillips

Screwdriver




ASSEMBLY STEPS

STEP 1

Carefully remove desktop (**A**) from packaging and set on table. Cut ties from desktop.




STEP 2




STEP 3

Plug the power cable (**H**) into the wall and press the switch on the right side to raise the desktop. Hang keyboard tray over pre-installed screws, and tighten screws using the allen key (**E**). The USB 2.0 port allows for charging phone, tablet, or other device.



STEP 4



AUTION!









Keep monitor and laptop base fully on the desktop.

Follow the cable routing instructions to avoid the potential to pinch cables.

Leave enough slack in cable to allow for full range of vertical motion (15" / 38 cm).

Raise desktop slowly to keep items stable.

Failure to follow these instructions may result in property damage and/or personal injury.





If any parts are received damaged or defective, please contact us. We are happy to replace parts to ensure you have a fully functioning product.







help@vivo-us.com

www.vivo-us.com

For more VIVO products, check out our website at: www.vivo-us.com.