

Forbidding Instruction

shall be stopped as required.

flight experience.

safety instructions.

indirectly by the user.

bear the relevant responsibilities and losses.

In order to ensure the requirements of the electromagnetic environment of the aeronautical

within 10 km on both sides of the airport runway center line, 20 km from both ends of the runway, and on civil aviation routes and paths. During the period and area with radio control

orders issued by the relevant state departments, the model remote controllers and drones

Disclaimer and Safety Instruction

of this instruction manual, and maintain this manual for future reference.

For the convenience that you can use the product more safely, please carefully read all contents

1. In order protect the legitimate rights and interests of users, please read the instructions

disclaimers and safety instructions provided with this product before using this product.

7. This product is not suitable for being used by children under 14. Persons under the age

Once you start using this product, you are deemed to have read, understood, approved

requirements including but not limited to the instructions and safety instructions. The

user shall bear the relevant responsibilities and losses for all personal injury, accident,

property loss, legal disputes and other adverse events resulting from conflicts of use

caused by the use of safety instructions or force majeure, and the company will not

The company will not be responsible for any violation of the law that occurs directly or

Safety Instruction

1. This product is not suitable for being used by children under 14 and others with no full civil

2. This product has a high-speed rotating propeller and powerful flight power, which

airports, railways, highways, high-rise buildings, and electric wires.

Long press the one button on the remote

Landing key, the aircraft will stop flying

avoid unnecessary loss and damage.

control for 3 seconds to take off/

has certain danger during operation. Do not approach and touch the product while

4. When using this product, please keep away from the high electromagnetic interference


environment such as mobile phone base station and high power transmitting equipment.


and accepted all terms and conditions of the product's instructions, disclaimers and

4. In the process of using this product, please strictly observe and implement the

of 14 and at the age of 14 need to be supervised and guided by adults with drone

radio station (station), it is forbidden to use various models of remote control and drones





27、请使用原厂配置的充电线充电,请勿使用其他品牌和有破损的充电线充电。

28、请与高速旋转的螺旋桨保持安全距离,以免发生绞伤、割伤危险。

30、飞行器要在尽可能远离其他电器设备和磁性物件的地方使用,它们

29、模型不要靠近耳朵使用!误用可能导致听力损坏。

32、电机为发热部件,请勿触碰,以免发生烫伤危险。

31、请不要短路、挤压电池,以免发生爆炸。

可能会造成相互干扰。

5. When using this product, please stay away from all kinds of manned aircraft.

7. This product is non-waterproof, so please keep it away from water.

10. Do not hover or fly over the crowd. Don't use it to scare other people.

. Do not operate this product near a place with playing children.

between the drone and the person or animal.

had physical discomfort and so on.

immediately and replace the accessory.

drone to direct sunlight for a long time.

strictly follows this safety precaution

24. Do not mix different types of batteries

Please fly the drone within the operator's visual range.

wind or low temperature.

6. Do not use this product in harsh environments such as rain, lightning, dust, fog, snow,

8. When operating this product, please always maintain a safe space of about 10 meters

12. Do not use this product to chase vehicles or affect the normal operation of the vehicle

13. In non-emergency situations, do not turn off the motor while the product is flying in

14. This product can not be used when the operator is drunk or fatigue, has taken drugs or

16. Drones with abnormal working conditions may case an accident. Please avoid starting the propeller or flying the drone in such conditions.

19. Do not operate this product in the no-fly zone stipulated by laws and regulations.

20. Due to the wide variety of materials used in the aircraft, high temperatures would

damage the internal structure of the drone and cause unpredictable consequences

23. If you lend the device to others, please make sure that the operator understands and

26. Do not approach flammable materials (such as blankets, solid wood furniture and

7. Please use the original configuration of the charging cable to charge, do not use the

changing cable of other brands and damaged charging cable.

28. Please keep a safe distance from the propeller rotating at high speed to avoid the risk

29. The model should be kept away from the ear! A wrong operation will cause hearing

30. The aircraft should be used as far as possible from other electrical equipment and

magnetic objects, because it may cause mutual interference.
31. Please do not connect the battery in short circuit or squeeze the battery to avoid

32. The motor is a hot component. Do not touch it to avoid the risk of burns.

Therefore, please keep the drone equipment away from heat and avoid exposing the

7. Do not attempt to prevent any moving parts in the work of this product.

18. Do not modify this product or use it for non-original purposes.


1. Please operate the product according to the product manual.

5. Do not use batteries that are inflated, leaking or damaged.

wooden boards and so on) in charging the battery.

2. Please use original accessories for maintenance and replacement.

5. Please check the product before each operation, including but not limited to the robustness of the parts, cracks and wear of the body and propeller, battery power, and the effectiveness of the indicator light. When an abnormality is found, stop using it



Matters Need Attention in Charging

1. The use of lithium batteries has certain risks and may cause significant losses to

2. If the battery leaks, please avoid contacting with skin and eyes. If it touches the

skin, wash it immediately with soap and water. If it comes into your eyes, rinse

1. Please use the original charger of the factory to charge, and it is forbidden to use

3. If the charger emits a suspicious odor, noise or smoke, please disconnect the

people and property. Please use them with caution and bear all relevant

immediately with plenty of water and go to the hospital immediately.

power supply immediately.

vour view sight in charging.

damaged charger or changer of other brands.

disconnect the power supply immediately.

2. Do not charge the battery that is inflated, leaking or damaged.

be placed for 10~15 minutes for being cooled down.

3. Do not overcharge the battery. When the battery is fully charged, please

6. The battery charging temperature should be between 0 ° C and 40 ° C.


This equipment is constituted by the electronic components and batteries.

For e-waste, please follow the local garbage disposal requirements for special

4. Do not charge near the surface of flammable materials (carpet, wooden floor,

solid wood furniture or the like) or conductive objects. Keep the battery within

5. Do not charge the battery immediately after using the product, instead it should



机壳

长按环绕飞行

₩ 螺旋桨 A

/ GPS模式


短按拍照


长按录像


丿 长按校准地磁


、 电源开关


摄像头


























"嘀"一声,退出无头模式。



2、本产品不适合未满14周岁的人士使用,14及14周岁以下人士需在有无人机飞行 经验的大人监督指导下使用。

3、一旦开始使用本产品,即视为您已阅读、理解、认可和接受本产品的说明书、 免责声明和安全须知的全部条款和内容。 、在使用本产品的过程中,请您务必严格遵守并执行包括但不限于说明书和安全 须知里的要求。对于违反安全须知所提示的使用行为或不可抗因素导致的一切

人身伤害、事故、财产损失、法律纠纷,及其他一切造成利益冲突的不利事件, 由用户自己承担相关责任和损失,本公司将不承担任何责任。 5、用户使用本产品直接或间接发生的任何违反法律规定的行为,本公司将不承担 任何责任。

、使用本产品时,请远离机场、铁路、高速公路、高层建筑、电线等危险环境。

4、使用本产品时,请远离手机基站,大功率发射设备等高电磁干扰的环境。

、本产品不适合未满14周岁及其他不具备完全民事行为能力的人士使用。

请勿在产品运行时靠近且触碰本产品。

2、本产品具有高速旋转的螺旋桨和强大的飞行动力,在运行时具有一定的危险性。



1. 使用锂电池有一定的风险,可能对人和财产造成重大的损失,请谨慎 使用, 自行承担所有相关责任。 2. 如果电池发生泄露, 请避免液体与皮肤和眼睛接触。若碰到皮肤, 请 立即以香皂和清水清洗。若接触眼睛,请立即以大量的清水冲洗并立即 3. 如果充电器发出可疑异味,噪音或者烟雾,请立即拔出电源。 1. 请使用原厂配送专用充电器充电,禁止使用破损或其他品牌充电器。


① 充电注意事项


2. 请勿对膨胀, 泄漏或破损的电池充电。 3. 请勿对电池过度充电。但电池完全充满电后,请拔出充电器。


4. 请勿在靠近易燃物(地毯、木地板、实木家具等)或导电的物体表面上充电 充电时请保持电池在视角范围内。 5. 切勿在使用产品后电池散热的时候立即充电需静置10~15分钟等待电池冷却。 6. 电池充电的温度应该介于0℃到40℃之间。


此设备由电子元件和电池构成。关于电子垃圾,请按照当地垃圾处理要求,进














行特殊处理。

