


BRAAAP PARTS LISTING // ST250cc

CONTENTS

- 1. HANDLEBAR / SPEEDOMETER / C
- 2. STEERING STEM / TRIPLE CLAMP
- 3. FRONT FENDER / SIDE GUARDS
- 4. REAR SUSPENSION / DRIVETRAIN
- 5. FUEL TANK / SEAT / IGNITION
- 6. REAR BRAKE PEDAL / SIDE STAND / GEAR LEVER
- 7. EXHAUST / AIR BOX / BATTERY / EGR
- 8. FRAME / FOOTPEG
- 9. SWING ARM / REAR GUARD
- 10. ELECTRICAL

- 11. HEAD LIGHT / TAIL LIGHT / INDICATOR
- 12. FRONT WHEEL / FRONT BRAKE
- 13. REAR WHEEL / REAR BRAKE
- 14. MIRRORS / TOOL KIT / USER MANUAL
- 15. 250cc ENGINE (INCLUDES ALL ENGINE COMPONENTS)


1. HANDLEBAR / SPEEDOMETER / CABLES



BP CODE	PART(S) DESCRIPTION
BP60-01-001	braaap Handlebar Standard Flat Black
BP60-01-002	braaap Handlebar Standard High Chrome
BP60-01-003	braaap Handlebar Drag Bar Black
BP60-01-004	braaap Handlebar Drag Bar Chrome
BP60-01-005	braaap Handlebar Grip Right
BP60-01-006	braaap Handlebar Grip Left
BP60-01-007	braaap Bar-End (Set)
BP60-01-008	braaap Speedometer Unit
BP60-01-009	braaap Speedometer Unit 48mm Black Face Bulb Lit
BP60-01-010	braaap Tachometer Unit 48mm Black Face Bulb Lit
BP60-01-011	braaap Speedometer Unit 48mm White Face Bulb Lit
BP60-01-012	braaap Tachometer Unit 48mm White Face Bulb Lit
BP60-01-013	braaap Speedometer Unit 60mm With Warning Black Face & Body
BP60-01-014	braaap Speedometer Unit 60mm With Warning Polished Face & Body
BP60-01-015	braaap Tachometer Unit 60mm Black Stainless Steel LED
BP60-01-016	braaap Tachometer Unit 60mm White Stainless Steel LED
BP60-01-017	braaap Speedo 60mm Black With Stainless Bezel
BP60-01-018	braaap Tachometer Unit Black Stainless Bezel Daytona
BP60-01-019	braaap Switch Block Left Hand Side
BP60-01-020	braaap Clutch Lever & Perch Assembly
BP60-01-021	braaap Clutch Lever
BP60-01-022	braaap Clutch Perch
BP60-01-023	braaap Clutch Perch Bolt
BP60-01-024	braaap Clutch Perch Nut
BP60-01-025	braaap Clutch Perch Mounting Bolts
BP60-01-026	braaap Switch Block Right Hand Side
BP60-01-027	braaap Nut
BP60-01-028	braaap Bolt M6 x 12
BP60-01-029	braaap Throttle Cable
BP60-01-030	braaap Clutch Cable Standard
BP60-01-031	braaap Clutch Cable Extended (High Bar)
BP60-01-032	braaap Speedometer Drive Cable
BP60-01-033	braaap Clutch Cable Holder
BP60-01-034	braaap Pan Head Screw
BP60-01-035	braaap Speedometer Unit Mount Bracket
BP60-01-036	braaap Brake Light Switch Cable
BP60-01-037	??
BP60-01-038	braaap Clutch Lever Rubber Cover
BP60-01-039	??
BP60-01-040	braaap Screw Hex Head
BP60-01-041	braaap Handlebar Clip-On Classic Chrome
BP60-01-042	braaap Handlebar Clip-On Classic Racing
BP60-01-043	braaap Handlebar Clubman Black
BP60-01-044	braaap Handlebar Clubman Chrome
BP60-01-045	braaap Handlebar British Standard Chrome
BP60-01-046	braaap Handlebar Dirt-Bike Style Chrome 7/8"
BP60-01-047	braaap Handlebar Low-Rise Black
BP60-01-048	braaap Handlebar Low-Rise Chrome
BP60-01-049	braaap Handlebar Type-A Chrome
BP60-01-050	braaap Handlebar Type-B Chrome
BP60-01-051	braaap Handlebar Type-C Chrome
BP60-01-052	braaap Grips Early-Barrel Style Black


BP60-01-053	braaap Grips Early-Barrel Style Gum
BP60-01-054	braaap Grips Early-Barrel Style White
BP60-01-055	braaap Grips Early-Barrel Style Brown
BP60-01-056	braaap Grips Early-Barrel Style Red-Flake
BP60-01-057	braaap Grips Early-Barrel Style Smoked Flake
BP60-01-058	braaap Grips Beston GT Black
BP60-01-059	braaap Grips Beston GT Gum
BP60-01-060	braaap Grips Waffle Black
BP60-01-061	braaap Clutch Lever Amal 534 Replica 7/8
BP60-01-062	braaap Clutch Lever Doherty 407P Replica 7/8
BP60-01-063	braaap Throttle Doherty-Style Single Cable
BP60-01-064	braaap Throttle Doherty-Style Dual Cable
BP60-01-065	braaap Throttle Cable Extended (High Bar)

2. STEERING STEM / TRIPLE CLAMP / FRONT FORKS



BP CODE	PART(S) DESCRIPTION
BP60-02-001	braaap Headstem
BP60-02-002	braaap Bottom Triple Clamp
BP60-02-003	braaap Headstem Nut Washer
BP60-02-004	braaap Headstem Lock Nut
BP60-02-005	braaap Headstem Upper Bearing Dust Cover
BP60-02-006	braaap Upper Neckstem Roller Bearing
BP60-02-007	braaap Lower Neckstem Roller Bearing
BP60-02-008	braaap Headstem Lower Bearing Dust Cover
BP60-02-009	braaap Reflector Triple Clamp Set
BP60-02-010	braaap Front Fork Right Hand Side
BP60-02-011	braaap Front Fork Left Hand Side
BP60-02-012	braaap Fork Seal Kit
BP60-02-013	braaap Fork Bleeders
BP60-02-014	braaap Front Brake Calliper Mount Bolts
BP60-02-015	braaap Bottom Triple Clamp Adjuster Bolts
BP60-02-016	braaap Headstem Nut
BP60-02-017	braaap Top Triple Clamp (Includes Base Handlebar Mounts)
BP60-02-018	braaap Top Handlebar Mounts
BP60-02-019	braaap Handlebar Mount Bolts
BP60-02-020	braaap Handlebar Mount Bolt Caps
BP60-02-021	braaap Top Triple Clamp Adjuster Bolts

3. FRONT FENDER / SIDE GUARDS



BP CODE	PART(S) DESCRIPTION
BP60-03-001	braaap Front Fender Matte Black
BP60-03-002	braaap Front Fender Gloss Black
BP60-03-003	braaap Front Fender Silver
BP60-03-004	braaap Front Fender Primed
BP60-03-005	braaap Front Fender Alloy Front 4"

BP60-03-006	braaap Front Fender Alloy Front 6"
BP60-03-007	braaap Front Fender Bracket Mounting Bolts
BP60-03-008	braaap Front Fender Bracket Mounting Nuts
BP60-03-009	braaap Front Fender Mounting Bolts
BP60-03-010	braaap Front Fender Mounting Nuts
BP60-03-011	braaap Side Guard Right Hand Side Red
BP60-03-012	braaap Side Guard Right Hand Side Gloss Black
BP60-03-013	braaap Side Guard Right Hand Side Matte Black
BP60-03-014	braaap Side Guard Right Hand Side Natural
BP60-03-015	braaap Side Guard Left Hand Side Red
BP60-03-016	braaap Side Guard Left Hand Side Gloss Black
BP60-03-017	braaap Side Guard Left Hand Side Matte Black
BP60-03-018	braaap Side Guard Left Hand Side Natural
BP60-03-019	braaap Side Guard Right Hand Side Rubber Grommets
BP60-03-020	braaap Side Guard Left Hand Side Rubber Grommets
BP60-03-021	braaap Speedometer Drive Cable Rubber Holder
BP60-03-022	braaap Front Guard Bracket Section A
BP60-03-023	braaap Front Guard Bracket Section B

4. REAR SUSPENSION / DRIVETRAIN



BP CODE	PART(S) DESCRIPTION
BP60-04-001	braaap Rear Shock Absorber
BP60-04-002	braaap Ugraded Shock Kit
BP60-04-003	braaap Washer A
BP60-04-004	braaap Rear Shock Mount Bolt
BP60-04-005	braaap Washer B
BP60-04-006	braaap Chain Slider Bracket
BP60-04-007	braaap Chain Slider Mount Bolt
BP60-04-008	braaap Chain Standard 428
BP60-04-009	braaap Chain Heavy Duty 428
BP60-04-010	braaap Chain O-Ring 428
BP60-04-011	braaap Chain Guard Mount Bolts
BP60-04-012	braaap Chain Guide Rubber
BP60-04-013	braaap Chain Guard Mount Bolts
BP60-04-014	braaap Chain Slider
BP60-04-015	braaap Front Sprocket

5. FUEL TANK / SEAT / IGNITION




BP CODE	PART(S) DESCRIPTION
BP60-05-001	braaap Ignition Barrel & Key Kit (Includes Fuel Cap)
BP60-05-002	braaap Ignition Barrel Mount Bolts
BP60-05-003	braaap Fuel Tank Red
BP60-05-004	braaap Fuel Tank Gloss Black
BP60-05-005	braaap Fuel Tank Matte Black
BP60-05-006	braaap Fuel Tank Silver

BP60-05-007	braaap Fuel Tank Primed
BP60-05-008	braaap Fuel Tank Vibration Grommets
BP60-05-009	braaap Fuel Tank Rubber Washer
BP60-05-010	braaap Fuel Tank Rubber Mount Block
BP60-05-011	braaap Fuel Tank Mount Bolts
BP60-05-012	braaap Washer
BP60-05-013	braaap Seat English Style
BP60-05-014	braaap Seat Racer Style Black (Hump Seat)
BP60-05-015	braaap Seat Racer Style Brown (Hump Seat)
BP60-05-016	braaap Seat Flat Style
BP60-05-017	braaap Fuel Tap Complete
BP60-05-018	braaap Fuel Tap Seal
BP60-05-019	braaap Fuel Tap Mount Bolts
BP60-05-020	braaap Fuel Line Black
BP60-05-021	braaap Fuel Line Filter
BP60-05-022	braaap Fuel Line Filter Chrome
BP60-05-023	braaap Butterfly Clips (Fuel Line)
BP60-05-024	braaap Seat Racer Style Rear Cowl Red
BP60-05-025	braaap Seat Racer Style Rear Cowl Matte Black
BP60-05-026	braaap Seat Racer Style Rear Cowl Natural

6. REAR BRAKE PEDAL / SIDE STAND / GEAR LEVER

F8



BP CODE	PART(S) DESCRIPTION
BP60-06-001	braaap Sidestand
BP60-06-002	braaap Sidestand Return Spring Outer
BP60-06-003	braaap Sidestand Mount Bolt
BP60-06-004	braaap Sidestand Nut
BP60-06-005	braaap Sidestand Return Spring Inner
BP60-06-006	braaap Rear Brake Pedal
BP60-06-007	braaap Rear Brake Pedal Return Spring
BP60-06-008	braaap Rear Brake Pedal Bush
BP60-06-009	braaap Rear Brake Pedal Mount Bolt
BP60-06-010	braaap Split Pin
BP60-06-011	braaap Gear Lever Mount Bolt
BP60-06-012	braaap Gear Lever

7. EXHAUST / AIR BOX / BATTERY / EGR



BP CODE	PART(S) DESCRIPTION
BP60-07-001	braaap Battery Cradle Complete
BP60-07-002	braaap Battery Cradle / Base Mount Bolt
BP60-07-003	braaap Battery Cradle / Base Nut
BP60-07-004	braaap Battery Cradle / Base Rubber Grommet
BP60-07-005	braaap Battery & Airbox Base

BP60-07-006	braaap Battery & Airbox Base Mount Bolts
BP60-07-007	braaap Battery & Airbox Base Mount Bracket
BP60-07-008	braaap Exhaust System Complete Chrome
BP60-07-009	braaap Exhaust System Complete Matte Black
BP60-07-010	braaap Muffler Reverse Cone Shorty Chrome
BP60-07-011	braaap Muffler Reverse Cone Shorty Matte Black
BP60-07-012	braaap Muffler Hot-Dog 1.50" / 1.75" Chrome
BP60-07-013	braaap Muffler Slash Cut 1.50" / 1.75" Chrome
BP60-07-014	braaap Muffler Wide Mouth Megaphone Chrome
BP60-07-015	braaap Muffler Tulip-End Chrome
BP60-07-016	braaap Muffler Hot-Dog
BP60-07-017	braaap Muffler Baseball Bat Chrome
BP60-07-018	braaap Muffler Cut-Away Chrome
BP60-07-019	braaap Muffler 450cc Spec
BP60-07-020	braaap Exhaust Heat Wrap Natural
BP60-07-021	braaap Exhaust Heat Wrap Black
BP60-07-022	braaap Airbox Assembly Complete
BP60-07-023	braaap Airbox Mount Bolt
BP60-07-024	braaap Air Filter
BP60-07-025	braaap Air Filter Pod Chrome
BP60-07-026	braaap Air Filter 42mm Foam
BP60-07-027	braaap Airbox Breather Hose
BP60-07-028	braaap Airbox Drain Hose
BP60-07-029	braaap Intake Boot
BP60-07-030	braaap Butterfly Clip Airbox/Drain Hoses
BP60-07-031	braaap EGR System (Exhaust Gas Recirculation)
BP60-07-032	braaap EGR Mounting Bracket
BP60-07-033	braaap EGR Mount Bolts
BP60-07-034	braaap Battery Rubber Strap
BP60-07-035	braaap EGR Vacuum Hose
BP60-07-036	braaap EGR Intake Braided Hose
BP60-07-037	braaap EGR Breather Hose
BP60-07-038	braaap EGR Vacuum Hose Butterfly Clips
BP60-07-039	braaap EGR Intake Braided Hose Butterfly Clips
BP60-07-040	braaap Exhaust Gasket Copper
BP60-07-041	braaap Exhaust Flange Bolts
BP60-07-042	braaap EGR Intake Port Manifold
BP60-07-043	braaap EGR Intake Port Manifold Spacer
BP60-07-044	braaap EGR Intake Port Manifold Mount Bolts
BP60-07-045	braaap EGR Breather Hose Butterfly Clips

8. FRAME / FOOTPEG




BP CODE	PART(S) DESCRIPTION
BP60-08-001	braaap Frame
BP60-08-002	braaap Model Plate
BP60-08-003	braaap Model Plate Rivets
BP60-08-004	braaap Upper Engine Mount Bracket
BP60-08-005	braaap Upper Engine Mount Bracket Bolts
BP60-08-006	braaap Nut
BP60-08-007	braaap Front Engine Cradle
BP60-08-008	braaap Front Engine Cradle Bolts A
BP60-08-009	braaap Front Engine Cradle Bolts B
BP60-08-010	braaap Nut M10 x 1.25
BP60-08-011	braaap Engine Mount Axle
BP60-08-012	braaap Engine Mount Axle Nut
BP60-08-013	braaap Footpeg Left Hand Side
BP60-08-014	braaap Footpeg Right Hand Side
BP60-08-015	braaap Footpeg Bracket Bolt
BP60-08-016	braaap Pillion Footpeg Left Hand Side
BP60-08-017	braaap Pillion Footpeg Right Hand Side
BP60-08-018	braaap Pillion Footpeg Mount Bolt
BP60-08-019	braaap Footpeg Set Triumph
BP60-08-020	braaap Footpeg Set Trail Style
BP60-08-021	braaap Saddle Bags (Subframe Mounting)

9. SWING ARM / REAR GUARD



BP CODE	PART(S) DESCRIPTION
BP60-09-001	braaap Swing Arm
BP60-09-002	??
BP60-09-003	??
BP60-09-004	??
BP60-09-005	??
BP60-09-006	??
BP60-09-007	??
BP60-09-008	braaap Rear Mud Flap
BP60-09-009	braaap Rear Guard Matte Black
BP60-09-010	braaap Rear Guard Gloss Black
BP60-09-011	braaap Rear Guard Chrome
BP60-09-012	braaap Rear Guard Primed
BP60-09-013	braaap Rear Frame Loop Weld On (Replaces Rear Guard)
BP60-09-014	??
BP60-09-015	??
BP60-09-016	??
BP60-09-017	??
BP60-09-018	??
BP60-09-019	braaap Chain Adjuster
BP60-09-020	braaap Swing Arm Axle
BP60-09-021	??
BP60-09-022	
BP60-09-023	
BP60-09-024	

10. ELECTRICAL



BP CODE	PART(S) DESCRIPTION
BP60-10-001	braaap Wiring Loom
BP60-10-002	braaap Solenoid
BP60-10-003	braaap Flasher Unit
BP60-10-004	braaap Rectifier
BP60-10-005	braaap Rectifier Mount Bolts
BP60-10-006	braaap Ignition Coil Kit (Includes Spark Plug Cap)
BP60-10-007	braaap Spark Plug Cap
BP60-10-008	braaap Coil Mount Bolts
BP60-10-009	braaap CDI Unit
BP60-10-010	braaap Battery
BP60-10-011	braaap Horn Mount Bolt
BP60-10-012	braaap Horn Standard Black
BP60-10-013	braaap Horn Chrome
BP60-10-014	braaap Stop Light Switch Wire
BP60-10-015	braaap Lead Wire Starter Motor

BP60-10-016	braaap Battery Eliminator
BP60-10-017	braaap Rectifier 12V 200W Single Phase
BP60-10-018	braaap Rectifier 12V 200W Three Phase
BP60-10-019	braaap Rectifier 12V 200W Single Phase With Battery Elimination
BP60-10-020	braaap Rectifier 12V 200W Three Phase With Battery Elimination
BP60-10-021	braaap Ignition Coil 12V Lucas Style
BP60-10-022	braaap Ignition Coil Dual Output 12V
BP60-10-023	braaap Alarm System Mongoose MCA500
BP60-10-024	braaap Switch Alloy With Push Button & Toggle
BP60-10-025	braaap Switch Alloy With Push Button
BP60-10-026	braaap Switch Alloy With Toggle
BP60-10-027	braaap Switch Black With Push Button & Toggle
BP60-10-028	braaap Switch Black With Push Button
BP60-10-029	braaap Switch Black With Toggle

11. HEAD LIGHT / TAIL LIGHT / INDICATOR



BP CODE	PART(S) DESCRIPTION
BP60-11-001	braaap Head Light Standard (Includes Bulbs)
BP60-11-002	braaap Head Light 7" Chrome Cafe Style
BP60-11-003	braaap Head Light 7" Black & Chrome Cafe Style
BP60-11-004	braaap Head Light 7" Chrome Side Mount Vintage
BP60-11-005	braaap Head Light 7" Black & Chrome Vintage
BP60-11-006	braaap Head Light 5.75" Bottom Mount Chrome
BP60-11-007	braaap Head Light 5.75" Bottom Mount Black With Chrome Rim
BP60-11-008	braaap Head Light 5.75" Bottom Mount Black Type A
BP60-11-009	braaap Head Light 5.75" Bottom Mount Black Type B
BP60-11-010	braaap Head Light 4.5" Bottom Mount Chrome
BP60-11-011	braaap Head Light 4.5" Bottom Mount Black
BP60-11-012	braaap Head Light Chrome With Hood
BP60-11-013	braaap Head Light 4.5" Bottom Mount Black With Chrome Rim
BP60-11-014	braaap Indicator Front Right Hand Side
BP60-11-015	braaap Indicator Front Left Hand Side
BP60-11-016	braaap Indicator Rear Left Hand Side
BP60-11-017	braaap Indicator Rear Right Hand Side
BP60-11-018	braaap Indicator Pair Daytona Black With Amber Lens
BP60-11-019	braaap Indicator Pair Daytona Chrome With Amber Lens
BP60-11-020	braaap Indicator Pair Daytona Chrome With Clear Lens
BP60-11-021	braaap Indicator Pair Type '71' Chrome With Clear Lens
BP60-11-022	braaap Indicator Pair Bullet Chrome With Clear Lens
BP60-11-023	braaap Indicator Pair 'Chopper' With Clear Lens
BP60-11-024	braaap Indicator Pair Bullet Large Chrome
BP60-11-025	braaap Indicator Pair Bullet Large Black
BP60-11-026	braaap Indicator Pair Bullet Slimline Chrome
BP60-11-027	braaap Indicator Pair Cat-Eye Black With Clear Lens
BP60-11-028	braaap Indicator Pair Cat-Eye Chrome With Clear Lens
BP60-11-029	braaap Indicator Pair Cat-Eye Chrome With Amber Lens
BP60-11-030	braaap Tail Light Standard
BP60-11-031	braaap Tail Light Early Style Black
BP60-11-032	braaap Tail Light Round Black
BP60-11-033	braaap Tail Light Round Chrome
BP60-11-034	braaap Tail Light Posh Black With Number Plate Bracket
BP60-11-035	braaap Tail Light 477 Lucas Style With Mounting Bracket
BP60-11-036	braaap Tail Light MT110 Lucas Style With Mounting Bracket
BP60-11-037	braaap Tail Light Sparto Polished Chrome
BP60-11-038	braaap Tail Light Sparto Black
BP60-11-039	braaap Tail Light 564 Chrome Plated Alloy
BP60-11-040	braaap Tail Light Jail Bars
BP60-11-041	braaap Tail Light 525 Lucas Style
BP60-11-042	braaap Tail Light 'Stop' Black
BP60-11-043	braaap Tail Light 477 Lucas Style Black
BP60-11-044	braaap Tail Light MT110 Lucas Style
BP60-11-045	braaap Tail Light MT211 Lucas Style
BP60-11-046	braaap Tail Light & Number Plate Bracket
BP60-11-047	braaap Number Plate Bracket Chrome
BP60-11-048	braaap Tail Light Bracket For Lucas Tail Lights
BP60-11-049	braaap Rear Fender Rubber Grommet

BP60-11-050	braaap Washer
BP60-11-051	braaap Indicator / Seat Bolt
BP60-11-052	braaap Reflector Rear Red
BP60-11-053	braaap Head Light Frame Bracket
BP60-11-054	braaap Head Light Bracket Cafe Syle Black
BP60-11-055	braaap Head Light Bracket Cafe Syle Polished Aluminium
BP60-11-056	braaap Head Light Bracket Modern Style Black
BP60-11-057	braaap Head Light Bracket Modern Style Chrome
BP60-11-058	braaap Head Light / Indicator Mount Left Hand Side
BP60-11-059	braaap Head Light / Indicator Mount Right Hand Side
BP60-11-060	braaap Indicator Bracket Rear Left Hand Side
BP60-11-061	braaap Indicator Bracket Rear Right Hand Side
BP60-11-062	braaap Head Light Globe
BP60-11-063	braaap Parkers Light Globe
BP60-11-064	braaap LED headlight Black with clear
BP60-11-065	braaap LED headlight Black with yellow

12. FRONT WHEEL / FRONT BRAKE



BP CODE	PART(S) DESCRIPTION
BP60-12-001	braaap Front Tyre 110/70 - 17"
BP60-12-002	braaap Front Tube 110/70 - 17"
BP60-12-003	braaap Front Wheel Kit (Includes Hub, Spokes & Rim)
BP60-12-004	braaap Front Rim
BP60-12-005	braaap Front Wheel Spoke Kit (Includes Spoke Nipples)
BP60-12-006	braaap Front Hub Complete
BP60-12-007	braaap Front Wheel Spacer Left Hand Slide
BP60-12-008	braaap Front Wheel Axle
BP60-12-009	braaap Speedometer Drive Unit
BP60-12-010	braaap Front Brake Disc
BP60-12-011	braaap Front Brake Assembly
BP60-12-012	braaap Front Brake Lever
BP60-12-013	braaap Front Brake Lever Mount Bolt
BP60-12-014	braaap Front Brake Master Cylinder
BP60-12-015	braaap Front Brake Line
BP60-12-016	braaap Front Brake Line Extended (High Bars)
BP60-12-017	braaap Front Brake Calliper
BP60-12-018	braaap Front Brake Pad (Set)
BP60-12-019	braaap Banjo Bolts
BP60-12-020	braaap Front Disc Bolts
BP60-12-021	braaap Front Wheel Axle Nut
BP60-12-022	braaap Front Rim Rubber Band
BP60-12-023	braaap Front Brake Assembly Extended (High Bar)

13. REAR WHEEL / REAR BRAKE



BP CODE	PART(S) DESCRIPTION
BP60-13-001	braaap Rear Tyre 130/70 - 17"
BP60-13-002	braaap Rear Wheel Kit (Includes Hub, Spokes & Rim)
BP60-13-003	braaap Rear Rim
BP60-13-004	braaap Rear Wheel Spoke Kit (Includes Spoke Nipples)
BP60-13-005	braaap Rear Hub Complete
BP60-13-006	braaap Rear Sprocket 428
BP60-13-006-42t	braaap Rear Sprocket 428 42t
BP60-13-007	braaap Rear Sprocket Locking Brackets
BP60-13-008	braaap Rear Sprocket Bolts
BP60-13-009	braaap Rear Wheel Spacer Left Hand Side
BP60-13-010	braaap Rear Wheel Axle
BP60-13-011	braaap Rear Brake Assembly
BP60-13-012	braaap Rear Brake Master Cylinder Push Rod (Includes Split Pin)
BP60-13-013	braaap Rear Brake Master Cylinder
BP60-13-014	braaap Rear Master Cylinder Mount Bolts
BP60-13-015	braaap Rear Brake Line
BP60-13-016	braaap Rear Brake Calliper
BP60-13-017	braaap Rear Brake Pads
BP60-13-018	braaap Banjo Bolts
BP60-13-019	braaap Rear Wheel Spacer Right Hand Side
BP60-13-020	braaap Rear Tube 130/70 - 17"
BP60-13-021	braaap Rear Wheel Axle Nut
BP60-13-022	braaap Rear Rim Rubber Band
BP60-13-023	braaap Rear Brake Disc (No Off-Set)
BP60-13-024	braaap Rear Brake Disc Bolts

14. MIRRORS / TOOL KIT / USER MANUAL

F14



BP CODE	PART(S) DESCRIPTION
BP60-14-001	braaap Mirror Standard Right Hand Side
BP60-14-002	braaap Mirror Standard Left Hand Side
BP60-14-003	braaap Bar-End Mirror Pair Continental Stainless
BP60-14-004	braaap Bar-End Mirror Pair Continental Chrome
BP60-14-005	braaap Bar-End Mirror Pair Continental Black
BP60-14-006	braaap Bar-End Mirror Pair Rectangular Chrome
BP60-14-007	braaap Mirror Pair 4" Round Stainless
BP60-14-008	braaap Mirror Pair 3" Round Universal Chrome
BP60-14-009	braaap Mirror Pair 3" Round Stainless & Aluminium
BP60-14-010	braaap Mirror Pair Rectangular Stainless & Aluminium
BP60-14-011	braaap Tool Kit (Includes Spanners, Screwdriver, Spark Plug Tool)
BP60-14-012	braaap User Manual (Provided With New Motorcycle Purchase)
BP60-14-013	braaap Cable Tie
BP60-14-014	braaap Cable Tie Re-Useable

15. ENGINE COMPLETE

E0



BP CODE	PART(S) DESCRIPTION
BP60-15-001	braaap Engine 250cc Complete
BP60-15-002	braaap Carburettor Café
BP60-15-003	braaap Inlet Manifold Café
BP60-15-004	braaap Kick Starter Café

ENGINE COMPONENTRY CONTENTS


15A. CYLINDER BLOCK & CYLINDER HEAD

15B. VALVE TRAIN

15C. RIGHT CRANK CASE COVER


15D. CRANK CASE

15A. CYLINDER BLOCK & CYLINDER HEAD




BP CODE	PART(S) DESCRIPTION
BP60-15-002	braaap Intake Valve Guide
BP60-15-003	braaap Exhaust Valve Guide
BP60-15-004	braaap Cylinder Block
BP60-15-005	braaap Cylinder Base Gasket
BP60-15-006	braaap Cylinder Head
BP60-15-007	braaap Cylinder Head Gasket
BP60-15-008	braaap Rocker Cover
BP60-15-009	braaap Rocker Cover Gasket
BP60-15-010	braaap Intake Pipe
BP60-15-011	braaap Bolt M6 X 20
BP60-15-012	braaap Bolt M6 X 25
BP60-15-013	braaap Bolt M8 X 84.6
BP60-15-014	braaap Nut
BP60-15-015	braaap Washer
BP60-15-016	braaap Oil Passage Washer
BP60-15-017	braaap Washer Copper
BP60-15-018	braaap Dowell O-Ring
BP60-15-019	braaap Bolt M6 X 12
BP60-15-020	braaap Bolt M6 X 20
BP60-15-021	braaap Bolt M6 X 35
BP60-15-022	braaap O-Ring 33.5 X 3
BP60-15-023	braaap Nut M6
BP60-15-024	braaap Dowell Pin
BP60-15-025	braaap Bolt M6 X 30
BP60-15-026	braaap Spark Plug NGK D7EA
BP60-15-027	braaap Spark Plug NGK D8EA

15B. VALVE TRAIN




BP CODE	PART(S) DESCRIPTION
BP60-15-028	braaap Valve Stem Oil Seal
BP60-15-029	braaap Push Rod Support Bracket
BP60-15-030	braaap Timing Sprocket (Cam Timing)
BP60-15-031	braaap Rocker Arm Support
BP60-15-032	braaap Rocker Arm Lower
BP60-15-033	braaap Rocker Arm Shaft
BP60-15-034	braaap Cam Shaft
BP60-15-035	braaap Cam Shaft Spring
BP60-15-036	braaap Push Rod
BP60-15-037	braaap Intake Valve
BP60-15-038	braaap Exhaust Valve
BP60-15-039	braaap Valve Spring Outer
BP60-15-040	braaap Valve Spring Inner
BP60-15-041	braaap Valve Seat Upper
BP60-15-042	braaap Valve Seat Spring Outer
BP60-15-043	braaap Valve Seat Spring Inner
BP60-15-044	braaap Split Cone Valve Seal
BP60-15-045	braaap Valve Clearance Adjustment Screw
BP60-15-046	braaap Bolt M8 X 30
BP60-15-047	braaap Rocker Arm Lock Nut
BP60-15-048	braaap Washer Timing Sprocket
BP60-15-049	braaap Washer
BP60-15-050	braaap Waved Washer
BP60-15-051	braaap O-Ring 20 X 2.5
BP60-15-052	braaap O-Ring 17 X 2.5
BP60-15-053	braaap Cam Shaft Stopper
BP60-15-054	braaap Bolt M6 X 12


15C. RIGHT CRANK CASE COVER



BP CODE	PART(S) DESCRIPTION
BP60-15-055	braaap Crank Case Cover Right Hand Side
BP60-15-056	braaap Crank Case Cover Right Hand Side Gasket
BP60-15-057	braaap Dip Stick
BP60-15-058	braaap Dip Stick O-Ring 18 X 3
BP60-15-059	braaap Sight Glass
BP60-15-060	braaap Clutch Rod
BP60-15-061	braaap Clutch Rod O-Ring
BP60-15-062	braaap Clutch Rod Return Spring
BP60-15-063	braaap Clutch Cam
BP60-15-064	braaap Split Pin 2 X 30
BP60-15-065	braaap Oil Seal 16 X 28 X 7
BP60-15-066	braaap Dowell Pin 8 X 14
BP60-15-067	braaap Right Hand Engine Cover Small
BP60-15-068	braaap Bolt M5 X 18
BP60-15-069	braaap Washer
BP60-15-070	braaap Bolt M6 X 40
BP60-15-071	braaap Bolt M6 X 50


15D. CRANK CASE






BP CODE	PART(S) DESCRIPTION
BP60-15-072	braaaap Centre Crank Case Right Hand Side
BP60-15-073	braaaap Centre Crank Case Gasket
BP60-15-074	braaaap Centre Crank Case Left Hand Side
BP60-15-075	braaaap Screen Filter Cover
BP60-15-076	braaaap Pin Retaining Block
BP60-15-077	braaaap Pin
BP60-15-078	braaaap Pin Spring
BP60-15-079	braaaap Screen Filter
BP60-15-080	braaaap Screen Filter Spring
BP60-15-081	braaaap Crank Case Breather
BP60-15-082	braaaap Crank Case Breather Butterfly Clips
BP60-15-083	braaaap Clutch Cable Adjusting Support Bracket
BP60-15-084	braaaap Bolt M6 X 100
BP60-15-085	braaaap Screw Stud A M8 X 141
BP60-15-086	braaaap Screw Stud B M8 X 137
BP60-15-087	braaaap Pin Retaining Assembly
BP60-15-088	braaaap Oil Seal 14 X 28 X 7
BP60-15-089	braaaap O-Ring 35.5 X 3
BP60-15-090	braaaap O-Ring 13 X 2.5
BP60-15-091	braaaap Bolt M6 X 55
BP60-15-092	braaaap Sump Plug
BP60-15-071	braaaap Bolt M6 X 50
BP60-15-093	braaaap Sump Plug Washer
BP60-15-094	braaaap Dowell Pin 10 X 14
BP60-15-095	braaaap Bolt M6 X 20

15E. OIL PUMP & OIL FILTER




BP CODE	PART(S) DESCRIPTION
BP60-15-096	braaaap Oil Pump Shaft
BP60-15-097	braaaap Oil Pump Assembly
BP60-15-098	braaaap Oil Pump Body
BP60-15-099	braaaap Oil Pump Cover
BP60-15-100	braaaap Oil Filter Body
BP60-15-101	braaaap Oil Pump Drive Sprocket
BP60-15-102	braaaap Oil Pump Rotator Gear Inner
BP60-15-103	braaaap Oil Pump Rotator Gear Outer
BP60-15-104	braaaap Oil Filter Assembly
BP60-15-105	braaaap Oil Filter Cover
BP60-15-106	braaaap Oil Filter Intake Pipe
BP60-15-107	braaaap Oil Filter Spring
BP60-15-108	braaaap Oil Filter Thrust Washer
BP60-15-109	braaaap Oil Filter Cover Gasket
BP60-15-110	braaaap Primary Drive Gear
BP60-15-111	braaaap Oil Pump Drive Sprocket
BP60-15-112	braaaap Bolt M6 X 35
BP60-15-113	braaaap Nut
BP60-15-114	braaaap Oil Pump Chain Guide
BP60-15-115	braaaap Oil Pump Drive Chain
BP60-15-116	braaaap Oil Pump Dowell Pin
BP60-15-117	braaaap Bolt M3 X 8
BP60-15-118	braaaap Nut M6
BP60-15-119	braaaap Bolt M5 X 12
BP60-15-120	braaaap Bolt M6 X 12
BP60-15-121	braaaap Retaining Pin

15F. STARTING MOTOR



BP CODE	PART(S) DESCRIPTION
BP60-15-123	braaap Starting Motor
BP60-15-124	braaap Dual Gear Set A
BP60-15-125	braaap Dual Gear Set B
BP60-15-126	braaap Starting Motor Drive Sprocket
BP60-15-127	braaap Dual Gear Set Washers
BP60-15-128	braaap Dual Gear Set A Shaft
BP60-15-129	braaap Dual Gear Set Needle Bearings
BP60-15-130	braaap Starting Clutch Stopper
BP60-15-019	braaap Bolt M6 X 12
BP60-15-131	braaap Bolt M6 X 30


15G. MAGNETO



BP CODE	PART(S) DESCRIPTION
BP60-15-132	braaap Crank Case Cover Left Hand Side
BP60-15-133	braaap Front Sprocket Cover
BP60-15-134	braaap Inner Coil
BP60-15-135	braaap Starting Clutch
BP60-15-136	braaap Flywheel
BP60-15-137	braaap Stator Plate
BP60-15-138	braaap Wire Clamp
BP60-15-139	braaap Bolt M8 X 18
BP60-15-140	braaap Bolt M6 X 55
BP60-15-141	braaap Plug
BP60-15-142	braaap Left Hand Engine Cover Small
BP60-15-143	braaap Flywheel Lock Bolt
BP60-15-144	braaap Crankshaft Oil.Seal 50 X 34 X 7
BP60-15-145	braaap Flywheel & Clutch Assembly
BP60-15-146	braaap Crank Case Cover Left Hand Side Gasket
BP60-15-147	braaap O-Ring 27.5 X 2.5
BP60-15-148	braaap O-Ring 13.8 X 2.5
BP60-15-149	braaap O-Ring 63 X 3
BP60-15-150	braaap Bolt M5 X 16
BP60-15-151	braaap Bolt M5 X 30
BP60-15-152	braaap Bolt M6 X 12
BP60-15-153	braaap Bolt M6 X 30
BP60-15-154	braaap Bolt M6 X 45
BP60-15-155	braaap Starting Motor Cover
BP60-15-156	braaap Bolt M6 X 20
BP60-15-157	braaap Neutral Sensor Oil Seal


BP60-15-158	braaap Neutral Sensor
BP60-15-159	braaap Bolt M6 X 16

15H. CLUTCH



BP CODE	PART(S) DESCRIPTION
BP60-15-160	braaap Clutch Basket & Primary Gear
BP60-15-161	braaap Clutch Centre
BP60-15-162	braaap Clutch Friction Plates (X5)
BP60-15-163	braaap Clutch Plates (X4)
BP60-15-164	braaap Clutch Pressure Plate
BP60-15-165	braaap Clutch Plate Lifter
BP60-15-166	braaap Clutch Lifter Rod
BP60-15-167	braaap Clutch Spline Washer
BP60-15-168	braaap Circlip
BP60-15-169	braaap Bolt M6 X 22
BP60-15-170	braaap Clutch Assembly
BP60-15-171	braaap Clutch Spring Kit
BP60-15-172	braaap Bearing 6001
BP60-15-173	braaap Clutch Plate & Centre Kit (Includes Pressure Plate)
BP60-15-174	braaap Clutch Bush


15I. CRANKSHAFT & PISTON



BP CODE	PART(S) DESCRIPTION
BP60-15-175	braaap Crankshaft Assembly
BP60-15-176	braaap Piston Oil Ring Kit (X3)
BP60-15-177	braaap Piston
BP60-15-178	braaap Gudgeon Pin
BP60-15-179	braaap Conrod
BP60-15-180	braaap Crankshaft Right Hand Side
BP60-15-181	braaap Crankshaft Left Hand Side
BP60-15-182	braaap Conrod Pin
BP60-15-183	braaap Crankshaft Timing Gear
BP60-15-184	braaap Woodruff Key
BP60-15-185	braaap Crankshaft Bearing Right Hand Side
BP60-15-186	braaap Crankshaft Bearing Left Hand Side
BP60-15-187	braaap Roller Bearing
BP60-15-188	braaap Gudgeon Pin Retaining Circlip
BP60-15-189	braaap Piston Oil Ring A
BP60-15-190	braaap Piston Oil Ring B
BP60-15-191	braaap Piston Oil Ring C
BP60-15-192	braaap Woodruff Key
BP60-15-193	braaap Crankshaft Balancer (Driving Gear)
BP60-15-194	braaap Lock Nut


BP60-15-195	braaap Washer
BP60-15-196	braaap Flat Key
BP60-15-197	braaap Crankshaft Balancer (Driven Gear)
BP60-15-198	braaap Balancing Shaft
BP60-15-199	braaap Bearing 6303 (17 X 47 X 14)
BP60-15-200	braaap Bearing 6203 (17 X 40 X 12)

15J. TRANSMISSION




BP CODE	PART(S) DESCRIPTION
BP60-15-201	braaap Main Shaft Assembly
BP60-15-202	braaap Counter Shaft Assembly
BP60-15-203	braaap Starter Shaft Assembly
BP60-15-204	braaap Main Shaft
BP60-15-205	braaap Counter Shaft
BP60-15-206	braaap 1st Gear Counter Shaft
BP60-15-207	braaap Bush
BP60-15-208	braaap Bush
BP60-15-209	braaap 2nd Gear Main Shaft
BP60-15-210	braaap 2nd Gear Counter Shaft
BP60-15-211	braaap 3rd Gear Main Shaft
BP60-15-212	braaap 3rd Gear Counter Shaft
BP60-15-213	braaap 4th Gear Main Shaft
BP60-15-214	braaap 4th Gear Counter Shaft
BP60-15-215	braaap 5th Gear Main Shaft
BP60-15-216	braaap 5th Gear Counter Shaft
BP60-15-217	braaap Starting Driven Gear Set
BP60-15-218	braaap Starting Idler Gear
BP60-15-219	braaap Output Gear 16t 428 pitch
BP60-15-219-17t	braaap Sprocket 17t 428 pitch
BP60-15-220	braaap Washer 15 X 25 X 1.0
BP60-15-221	braaap Washer 15 X 30 X 1.0
BP60-15-222	braaap Washer 16.5 X 24 X 0.5
BP60-15-223	braaap Washer 20 X 26.5 X 0.5
BP60-15-224	braaap Washer 20 X 26 X 1.0
BP60-15-225	braaap Spline Washer
BP60-15-226	braaap Circlip
BP60-15-227	braaap Oil Seal 20 X 34 X 7
BP60-15-228	braaap Bolt M6 X 10
BP60-15-229	braaap Output Gear Locating Plate
BP60-15-230	braaap Bearing 6006
BP60-15-231	braaap Bearing 6204
BP60-15-232	braaap Bearing 6202 RS
BP60-15-233	braaap Circlip 16
BP60-15-234	braaap Circlip 24
BP60-15-235	braaap Friction Spring Retaining Plate
BP60-15-236	braaap Washer
BP60-15-237	braaap Spring
BP60-15-238	braaap Starting Ratchet
BP60-15-239	braaap Circlip 20
BP60-15-240	braaap Washer A
BP60-15-241	braaap Starting Gear
BP60-15-242	braaap Starting Shaft
BP60-15-243	braaap Base Spring
BP60-15-244	braaap Return Spring
BP60-15-245	braaap Sleeve
BP60-15-246	braaap Washer B
BP60-15-247	braaap Washer
BP60-15-248	braaap Needle Bearing

15K. GEAR SHIFTING ASSEMBLY




BP CODE	PART(S) DESCRIPTION
BP60-15-249	braaap Gear Shift Shaft Assembly
BP60-15-250	braaap Selecting Fork A
BP60-15-251	braaap Selecting Fork B
BP60-15-252	braaap Selecting Fork Shaft
BP60-15-253	braaap Selecting Fork C
BP60-15-254	braaap Cam
BP60-15-255	braaap Gear Positioning Limiter
BP60-15-256	braaap Return Spring
BP60-15-257	braaap Gear Selcting Shaft
BP60-15-258	braaap Gear Shifter
BP60-15-259	braaap Gear Shifter Spring
BP60-15-260	braaap Gear Shift Shaft Return Spring
BP60-15-261	braaap Gear Selector Drum
BP60-15-262	braaap Washer
BP60-15-263	braaap Bolt M6 X 20
BP60-15-264	braaap Needle Bearing
BP60-15-265	braaap Circlip 12
BP60-15-266	braaap Circlip 14
BP60-15-267	braaap Pin
BP60-15-268	braaap Bolt M6 X 30

15L. CARBURETOR



BP CODE	PART(S) DESCRIPTION
BP60-15-269	braaap Carburetor Assembly PZ30

15M. GEAR LEVER & KICKSTARTER



BP CODE	PART(S) DESCRIPTION
BP60-15-270	braaap Gear Lever Complete (Not Canti-Lever)
BP60-15-271	braaap Gear Lever Tip Rubber
BP60-15-272	braaap Gear Lever Arm
BP60-15-273	braaap Bolt M6 X 20
BP60-15-274	braaap Kickstarter Complete
BP60-15-275	braaap Kickstarter Rubber
BP60-15-276	braaap Circlip 13
BP60-15-277	braaap Pivot Bolt
BP60-15-278	braaap Spring
BP60-15-279	braaap 1/4 Ball Bearing
BP60-15-280	braaap Kickstarter Pivot Joint
BP60-15-281	braaap Kickstarter Arm
BP60-15-282	braaap Bolt M8 X 40