

keyscaper[®]
fan gear

Wireless USB Mouse


Product Manual
Version 1.0

THANK YOU!

Thanks for choosing Keyscaper!

Please read the following manual carefully to ensure you get the most out of your Wireless USB Mouse


Product Guide:



Index:

	Page
Putting in the Batteries	3
Syncing Your Mouse and Dongle	4

Putting in the Batteries:



Now that the cover/design is loose you can wiggle it off the rest of the way with a small side to side motion.

Gently slide the switch on the bottom of the mouse toward yourself. This will release the cover/design on the top of the mouse.

The batteries should be inserted as shown here.

You can now replace the cover/design by aligning the top of the cover with the right and left clickers. The fingers should grab onto the holes next to the scroll wheel. Now gently press the bottom of the cover until it clicks into place. If it does not click the first time press it again.