# keyscaper®

Bluetooth Earbuds
Product Manual

Please read the following manual carefully to ensure you get the most out of your Bluetooth Earbuds.

Includes:
Headphone/Control Pod in 'Jewelbox' packaging.

USB to USB-Micro charging cable

3 ear tip sizes (Small, Medium, Large)

About the Wireless Earbuds:
- Product Weight: 28g
- Battery: 55mAh
- Playtime: 4-5 hours
- Standby Time: 120 hours
- Charging Time: 2 hours

Before you begin:
1. Please fully charge the earphones and read instructions before the first-time use.
2. Select your ear tip size: Small, Medium, or Large. Find the size that fits perfectly. Gently clip tip to earbuds.
3. The cord should be worn in the back.

How to use:
1. Turn ON the Bluetooth function from your device.
2. Hold the Power button until blue light flashes.
3. Look for IB1-03 and PAIR.

Controls:
To change to the next song, short press the (**+**) button.

To repeat current song, short press the (**-**) button.

To go back, quickly short press the (**-**) button twice.

To increase volume, HOLD the (**+**) button.

To decrease volume, HOLD the (**-**) button.

Phone Controls:
To answer or hang up a call, press the middle (**o**) button.